



MARCHESAN

INSTRUCTIONS MANUAL



USAP



IDENTIFICATION

Dealer: _____

Owner: _____

Firm / Farm: _____

City: _____ State: _____

No. of the Certificate of Guarantee: _____

Serial / No.: _____

Date: _____ / _____ / _____ Invoice No.: _____

Product: _____

Notes: _____

Introduction

USAP and USAP Suprema planters were developed based on the plantation row units that equip the Tatu Marchesan planters and which have been tested for several years and used widely for a no-till plantation.

The frame allows several spacings between the row units, being their adjustments quick and easy. A single planter facilitates the plantation and the need for different spacings.

The permanent flotation control can follow an irregular terrain easily while keeping the seed depth uniformly for the proper plant germination.

A great clearance on the frame allows an excellent income, since the straw pass through the planter easily and there is no need to stop the plantation for cleaning up the residues.

Reduced transportation width; hydraulic system activation to fold the equipment frames.

This instructions manual contains the necessary information for the best performance of this planter. The operator must carefully read the entire manual before working with the equipment. Also, read and understand the safety recommendations.

For any further clarification or in the event of technical problems that may arise during the service, consult your dealer and the Technical Support department of the factory. They can ensure the fully functioning of your TATU planter.



Table of contents

1. To the owner	5
2. To the operator	6 to 12
Lifting points	10
Safety stickers	11 & 12
3. Components	13 to 18
USAP SUPREMA	13
USAP SUPREMA - central seed hopper	14
USAP SUPREMA - fertilizer hopper and central seed hopper	15
USAP - Seed and fertilizer hopper	16
Seed row units models for USAP	17 & 18
4. Data sheet	19 to 22
Tractor required table (cv) / Oil flow table	19
USAP dimensions	20 to 22
5. Assembly	23 to 62
Smaller inner bar assembly	23
Greater inner bar assembly	24
Frame assembly	25
Extension bars assembly	26
Hoppers assembly	27
Ladder assembly	28
Row marker assembly	29 to 31
Control valve	32
Hydraulic circuit with 2 Precision Planting turbines (2014 series)	33 & 34
Hydraulic circuit with 2 Precision Planting turbines	35 & 36
Hydraulic circuit with 3 Precision Planting turbines	37 & 38
Hydraulic circuit with 2 PP turbines and 1 CSH turbine (2014 series)	39 & 40
Hydraulic circuit with 2 PP turbines and 1 CSH TATU turbine	41 & 42
Hydraulic circuit with 3 PP turbines and 1 CSH TATU turbine	43 & 44
Hydraulic circuit with 3 PP turbines and 2 CSH TATU turbines	45 & 46
Wheelset hydraulic circuit	47 & 48
Articulation hydraulic circuit	49
Drawbar articulation hydraulic circuit	50
Row marker hydraulic circuit	51 & 52
APT hydraulic circuit	53 & 54
USAP electric system assembly (with clutch)	55
Lifting sensor	56
Seed row unit with disc blade (mechanical)	57
Seed row unit with disc blade (Titanium)	58
Seed row unit with disc blade (Precision Planting)	59
Seed row unit with disc blade (Vdrive)	60
Hose assembly on the seed hoppers	61
Hose assembly on the fertilizer hoppers	62

Table of contents

6. Set-up instructions	63 to 75
Tractor preparation / Hitching to the tractor	63 & 64
Setting the planter to transport position	65 & 66
Spacing between row units / Positioning the row units on the frame	67
Spacing tables	68
Procedures to change the spacing	69 & 70
Filling up the planter	71
Planning the plantation - Correct seed rate	72
Calculation of seeds per hectare	73
Procedures before the plantation / Ideal working speed	73
Graphite powder use / List of standard seed plates in the planter	74 & 75
7. Adjustments and operations	76 to 95
Seeds distribution / Procedures to change the sprockets	76 & 77
Mechanical seeds distribution table - (tire Ø 831/ 921)	78
Precision planting seeds distribution table - (tire Ø 831/ 921)	79
Mechanical seed distribution table - (tire Ø 921/ 1072)	80
Precision planting seed distribution table - (tire Ø 921/ 1072)	81
Calculation of the amount of seeds	82
Fertilizer distribution / Procedures to change the sprockets	83 & 84
Fertilizer distribution table	85
Practical test of seed and fertilizer distribution	86
Auxiliary calculation for fertilizer distribution	87
Oscillating disc blades / Opening the seed furrows	88
Opening the seed furrows / Seed depth and floating range of the row unit	89 & 90
Press wheels adjustment	90
Electromagnetic clutch	91
Row markers / Working angle	92 & 93
Working angle related to the soil	94
Operations - Important points	95
8. Maintenance	96 to 101
Lubrication	96
Lubrication points	97 & 98
Fertilizer metering maintenance	99
Cleaning the seed metering / Maintenance of the row hubs	100
How to replace the tires	101
9. Optional	102 to 105
Seed plates	102
Depth control system with gauge wheel	103
TATU precision agriculture (APT)	104
TATU precision agriculture - Components connection	105

Table of contents

USAP TITANIUM APOLLO	
1. Assembly	106 & 107
Seed dosing system for mechanical machines	107
Components and assembly	107
2. Set-up instructions	108
TITANIUM standard and optional seed plates	108
3. Maintenance	109 & 110
Main technologies	109
Graphite powder use	110
USAP Precision Planting vacuum seed meter	
1. Assembly	111 & 112
Turbine with hydraulic motor / Hydraulic activation	112
2. Set-up instructions	113 to 115
Precision Planting seed plates	113 to 115
3. Adjustments and operations	116 to 121
Changing the metering set	116
Baffle position	117
vDrive components maintenance	117
Appropriate suction / Vacuum meter suction verification	118
Vacuum meter installation / Vacuum meter assembly	119
Set-up instructions	119
Vacuum meter recommendations / Troubleshooting tips	120
Stopping the seed flow	121
4. Maintenance	122
Pneumatic sealing	122
Seed metering maintenance - Precision Planting	122
USAP Suprema with CSH	
1. Assembly	123 & 124
Air duct assembly on the central seed hopper	124
2. Maintenance	125
Cleaning the central seed hopper	125
Planter maintenance	
1. Maintenance	126 to 130
Planter maintenance	126
Troubleshooting	127 & 128
Tires inflation / Maintenance precautions	129
Torque table	130
2. Important	131
3. Notes	132

To the owner

The acquisition of any TATU product assures to the original purchaser the following rights:

- Warranty certificate;
- Instructions manual;
- Technical assistance by the dealer on equipment delivery.

However, the owner must check the condition of the equipment on delivery, as well as knowing the warranty terms.

Special attention should be given to the safety recommendations, operation precautions and maintenance of the equipment.

The instructions in this manual indicates how to get the best performance and allow the operator to get maximum income, increasing the equipment lifetime.

This manual should be read by operators and maintenance staff.

Important




- Only people who own a full knowledge of the tractor and equipment must operate them;
- Marchesan is not responsible for any damage caused by accident on transporting, incorrect utilization or inadequate storage, either by negligence and/or lack of experience from any person;
- Marchesan is not responsible for any damage caused by unpredictable situations or the incorrect use of the equipment.

General information

Right and left hand side indication are made observing the equipment from the rear.

To order any parts or request assistance services, it is required to provide the data contained on the nameplate, which is located on the equipment frame.



NOTE

The warranty shall not be applied to any equipment, or any parts thereof, which has been altered elsewhere than at the place of manufacture or which the original purchaser thereof, at retail, has used or allowed to be used parts, not made or supplied by Marchesan S/A.


To the operator

Be careful with the environment



Dear user!

Respect the ecology. Do not throw trash away. This gesture of goodwill helps to protect our environment.



Products such as oil, fuel, filters, batteries and others are spilled to the soil and can penetrate to the underground layers, compromising nature. Ecological and conscious disposal of them should be done.

Working safely




- Security aspects must be carefully observed to avoid accidents.
- This symbol is a warning used to prevent accidents.
- The instructions under this symbol refers to the safety of the operator or third parties, therefore they should be carefully read and observed.

USAP and USAP SUPREMA planters are simple to operate, requiring however the basic and essential cautions to their handling.

Always keep in mind that safety requires constant attention, observation and prudence during plantation, transportation, maintenance and storage.



Read and understand the information before making any adjustment or maintenance.



Before activating the equipment, check if there are no people or animals on the row operation area or over the equipment.



Have extreme caution when operating with the power take-off (PTO). Do not get closer during operation.

To the operator



Never use your bare hands to check hydraulic leaks, the high pressure can cause injuries.



Never attempt to change the adjustments, clean or lubricate the equipment when the same is switched on or in movement.




Be careful while driving on slopes. Risk of overturn.



Prevent that chemical products (i.e.: fertilizers, treated seeds) make any contact with your skin or clothes.



Keep access and work places clean and free from oil and grease. Risk of accidents.



Never transport the equipment on highways or paved roads during the night. Avoid that the tractor wheels touch the drawbar in sharp turns.



The presence of any other people on the tractor or equipment is strictly forbidden.



Have extreme caution when driving under electrical power lines. Any contact may result in severe shocks, injuries or death.



For your protection and safety, always wear adequate clothes and footwear while operating the equipment.



Always use the safety locks to carry out maintenance operations and to transport the equipment.

To the operator



- Only trained and qualified personnel are allowed to operate the equipment.
- While working or during transportation, only the presence of the operator is allowed on the tractor.
- Do not allow children to play or to get over the equipment while it is operating, during transportation or storage.
- Have full knowledge of the soil before starting to work. Provide the delineation of obstacles or hazardous locations.
- Use personal protective equipment (PPE).
- Wear appropriate clothes and footwear. Avoid clothes that are either loose or hanging from the body, which may become entangled in moving parts.
- Never operate the equipment without its **protective devices**.
- Be careful while hitching the equipment to the tractor.
- Wear appropriate gloves to work near the disc blades.
- When lifting or lowering the planter, check if there are no people or animals close or under the equipment.
- Never attempt to change the adjustments, clean or lubricate the equipment while it is moving.
- In case of emergency, know how to stop the tractor and planter quickly.
- Always shut down the engine, remove the key and use the handbrake before leaving the tractor seat.
- Only drive the equipment using a tractor with appropriate power.
- Carefully check the transport width on narrow locations.
- Whenever you unhitch the equipment, either in the field or shed, do it on a flat and firm surface and use the parking stands. Make sure the equipment is properly supported.
- Do not drive the equipment under the influence of alcohol or any sooting/stimulating medicine, as it may result in a serious accident.
- In case of a fire outbreak or any possible hazard, the operator must leave the area as fast as possible and look for a safe place. Always have emergency numbers at hands.
- Do not allow people or animals to get under the equipment at any time.
- Please check the general safety instructions on the back cover of this manual.

To the operator

Transportation over truck or trailer




Marchesan does not advise the equipment traffic on highways, because this practice involves serious security risks in addition to being prohibited by the current existing traffic law. The transportation for long distances should be done on truck, trailer or other by following these safety guidelines:

- Use adequate ramps to load or unload the equipment. Do not make the loading on ditch banks, it can cause a serious accident.
- When lifting with a hoist, use the appropriate points to lift.
- Use the parking stands to support the equipment properly.
- The equipment drawbar must be lifted and locked in a vertical position or it must be removed and locked to the load.
- Fasten the moving parts that may get loose and cause accidents.
- Underpin the equipment wheels appropriately.
- Use chock blocks and safety chains to secure the equipment to the truck or trailer during the transport.
- After 8 to 10 km transporting, please inspect the load condition. Repeat this procedure every 80 to 100 km. Give more attention when transporting the equipment on rough roads, slopes and other adverse conditions.
- Always be careful with the load height, especially when passing under electrical power lines, bridges and others.
- Check all laws and regulations regarding the height limits and load width while transporting the equipment to the truck or trailer. If necessary use banners, lights and other devices in order to give adequate warning to the other drivers.

To the operator

Lifting points

USAP and USAP SUPREMA planters have adequate lifting points, being two in the rear and one in the front part of the equipment. When lifting with a hoist, it is essential to hitch the cables to these points.



To the operator

Safety stickers

The safety stickers warn about the equipment points that require more attention and they should be kept in good repair. If these stickers become damaged or illegible, replace them. Marchesan provide stickers, upon request and indication of the respective serial number.



05.03.03.3621



05.03.03.1428



05.03.03.1425



05.03.03.1426



05.03.03.2949




05.03.03.1424

When the planter is equipped with a row marker.

To the operator



ADVERTÊNCIA / WARNING / ADVERTENCIA		
Cuidados Durante o Trabalho e Transporte As escadas de acesso à plataforma devem ser erguidas. Nunca transporte pessoas sobre a plataforma, escada ou qualquer outra parte da plantadeira.	Precautions During Working and Transportation The ladders to the platform must be raised. Never transport any person on the ladders, seat, platform or any planter parts.	Cuidados Durante el Trabajo y el Transporte Las escaleras de acceso a la plataforma deben estar levantadas. Nunca transporte personas sobre la plataforma, escalera o cualquier otra parte de la sembradora.
Cuidados Durante as Regulagens Todas as tampas de proteção devem ser mantidas no lugar e em bom estado, para evitar acidentes.	Precautions During Adjustments All the protection guards must be kept in place and in good conditions to avoid accidents.	Cuidados Durante las Regulaciones Todas las tapas de protección deben ser mantenidas en su sitio y en buen estado, para evitar accidentes.
		05.03.03.1565




Safety stickers

Model	Sticker code	Sticker code	Sticker code
USAP	05.03.03.3853	05.03.03.3854	05.03.03.3873 USAP logo
USAP SUPREMA	Small logo	Big logo	05.03.03.3888 USAP SUPREMA logo
USAP CSH (Central seed hopper)	05.03.03.4334 USAP CSH rear	05.03.03.4335 TATU rear logo	_____
	05.03.03.4336 USAP CSH front	05.03.03.4337 TATU front logo	_____
	05.03.03.4338 USAP CSH lateral	05.03.03.4339 TATU lateral logo	_____

Components

USAP SUPREMA


- | | |
|----------------------------------|--------------------------------|
| 01 - Central frame | 02 - Left lateral frame |
| 03 - Right lateral frame | 04 - Lateral wheelsets |
| 05 - Central wheelset | 06 - Seed hopper |
| 07 - Telescopic bar | 08 - Extension bars |
| 09 - Drawbar | 10 - Transport lock |
| 11 - Pneumatic seed row unit | 12 - Ladder |
| 13 - Hydraulic marker | 14 - Tool box |
| 15 - Water reservoir (25 liters) | 16 - Three-point hitch drawbar |
| 17 - Pneumatic system | 18 - Open end wrench (71) |
| 19 - Pressure adjustment lever | |



Components

USAP SUPREMA - central seed hopper


- | | |
|----------------------------------|--------------------------------|
| 01 - Central frame | 02 - Left lateral frame |
| 03 - Right lateral frame | 04 - Lateral wheelsets |
| 05 - Central wheelset | 06 - Central seed hopper |
| 07 - Telescopic bar | 08 - Extension bars |
| 09 - Drawbar | 10 - Transport lock |
| 11 - Pneumatic seed row unit | 12 - Ladder |
| 13 - Hydraulic marker | 14 - Tool box |
| 15 - Water reservoir (25 liters) | 16 - Three-point hitch drawbar |
| 17 - Pneumatic system | 18 - Open end wrench (71) |
| 19 - Pressure adjustment lever | |



Components

USAP SUPREMA - fertilizer hopper and central seed hopper


- | | |
|--------------------------------|---------------------------|
| 01 - Central frame | 02 - Left lateral frame |
| 03 - Right lateral frame | 04 - Lateral wheelsets |
| 05 - Central wheelset | 06 - Central seed hopper |
| 07 - Telescopic bar | 08 - Extension bars |
| 09 - Drawbar | 10 - Transport lock |
| 11 - Pneumatic seed row unit | 12 - Ladder |
| 13 - Tool box | 14 - Fertilizer hopper |
| 15 - Disc blades | 16 - Open end wrench (71) |
| 17 - Pressure adjustment lever | |



Components


USAP - Seed and fertilizer hopper

- | | |
|--------------------------------|---------------------------|
| 01 - Central frame | 02 - Left lateral frame |
| 03 - Right lateral frame | 04 - Lateral wheelsets |
| 05 - Central wheelset | 06 - Seed hopper |
| 07 - Telescopic bar | 08 - Extension bars |
| 09 - Drawbar | 10 - Transport lock |
| 11 - Seed row unit | 12 - Ladder |
| 13 - Tool box | 14 - Fertilizer row unit |
| 15 - Disc blades | 16 - Open end wrench (71) |
| 17 - Pressure adjustment lever | 18 - Gearbox |




Components


Seed row unit models for USAP



Precision planting
seed row unit with
steel cable




Precision planting
seed row unit



Precision planting
seed row unit with
mini hopper

Components

Seed row unit models for USAP



Data sheet

Type: Planter
 Model: USAP and USAP Suprema
 Spacing between row units (mm): 450, 500 and 550
 Working width: 7,500 mm to 17,890 mm
 Transport width: 6,500 mm
 Height: 2,700 m
 Transport length: 9,500 mm to 23,000 mm
 Maximum transport speed: 15 km/h
 Tires:
 Central tires: 14 x 17.5/14 TR SK 900 (**55 PSI**)
 Central tires: 385/65 R 22.50 D 711 DRC 15-19.50 20 tarps (**130 PSI**)
 Lateral tires: 12 x 16.50 / 12 tarps TR SK 900 (**65 PSI**).

NOTE * Series connection.


USAP seed hopper		
Tractor required (cv) table		
Number of row units	USAP	USAP SUPREMA
18	120 - 140	160 - 180
20	140 - 160	180 - 200
22	150 - 170	190 - 210
24	160 - 180	200 - 220
25	170 - 190	210 - 230
26	180 - 200	220 - 240
27	190 - 210	230 - 250
28	200 - 220	240 - 260
29	200 - 220	240 - 260
30	210 - 230	250 - 270
32	220 - 240	260 - 280
33	230 - 250	270 - 290
35	240 - 260	280 - 300
36	250 - 270	300 - 320
40	280 - 300	320 - 340
42	290 - 310	340 - 360
45	310 - 330	350 - 370
46	320 - 340	370 - 390
50	350 - 370	400 - 420

Oil flow table		
USAP		
USAP SUPREMA		
Model	Flow rate (Liters)	
Central hopper turbine	10 to 25	
Precision planting turbine	(05 to 24)*	
APT engine	15 to 30	
Alternator engine	20	

USAP seed and fertilizer hopper		
Tractor required (cv) table		
Number of row units	USAP	USAP SUPREMA
18	150 - 170	180 - 200
20	170 - 190	200 - 220
22	180 - 200	210 - 230
24	200 - 220	230 - 250
25	210 - 230	240 - 260
26	220 - 240	250 - 270
27	230 - 250	260 - 280
28	240 - 260	270 - 290
29	250 - 260	280 - 300
30	260 - 280	290 - 310
32	270 - 290	300 - 320



Data sheet

USAP dimensions



Data sheet

USAP dimensions



Data sheet

USAP dimensions

USAP/USAP SUPREMA dimensions						
Number of row units	Working width (A)	Total width without markers (B)	Total length (C)	Height when supported on the ground (D)	Transport length (E)	Transport length without markers (F)
18	8880	8940	9290	2900	11170	6500
20	9880	8940	9290	2900	11170	6500
22	10880	9860	10300	2900	11300	6500
24	11800	12040	10300	3020	12290	6500
25	12300	12910	10300	3020	12800	6500
26	12800	12910	10300	3020	12800	6500
27	13300	14910	10300	3020	12300	6500
28	13800	14910	10300	3020	12300	6500
29	14300	14910	10300	3020	12300	6500
30	14800	14910	10300	3020	12300	6500
32	15800	15890	10300	3020	13200	6500
33	16300	16280	11500	3020	14780	6500
35	17300	17890	11500	3020	14780	6500
36	17800	17890	11500	3020	18600	6500
40	19800	20900	14900	3020	18600	6500
42	20800	20900	14900	3020	18600	6500
45	22300	20900	14900	3020	18600	6500
46	22800	22400	14900	3020	19400	6500
50	22800	22400	14900	3020	19400	6500

Assembly

The planters leave the factory semi-assembled to facilitate transportation, being necessary the placement of just a few components by following the instructions below:


Smaller inner bar assembly

Before assembling the telescopic bar (A) to the central frame (B) it is necessary to place the inner bar (C). To do so, follow the instructions:

First of all, loosen up the bolts that fasten the plate (D), which is located below the central frame (B). Then, place the shims (E) inside the central frame.

Lastly, place the inner bar (C) on the telescopic bar (A) and on the central frame (B). Tighten up the bolts of the plate (D) again.

Assemble the transport lock (F) to the telescopic bar (A) using bolts (G), spring washers and nuts.



Assembly

Greater inner bar assembly


For greater equipments, the telescopic bar assembly differs from the smaller ones.

Assemble the telescopic bar (A) to the central frame (B). It is not necessary to place the inner bar (C), as it leaves the factory already assembled.

Use the bolt (D), spring washer and nut to join the telescopic bar (A) with the central frame (B).

The pin (E), castle nut and cotter pin work as a guide to assemble the telescopic bar (A) to the central frame (B) to facilitate the placement and tightening of the bolts (D).

Fasten the plate (F) to the frame (B) using a bolt (G) and spring washer.



Assembly


Frame assembly

Couple the right (A) and left (B) lateral frames to the central (C) one, using the axles (D) and fastening with bolts, spring washers and nuts.

Fasten the telescopic inner bar (E) using bolts (F), spring washers and nuts.

Couple the parking stand (G) to the telescopic bar (E) using a pin (H) and lock pin.

Assemble the telescopic bar lock (I) to the central frame (C) using an axle (J) lock.



NOTE To remove the pin (D), use the bushing and the retrieving axle that can be found inside the components box.

Assembly


Extension bars assembly

Assemble the extension bars (K) to the right (A) and left (B) frames using an axle (L) on one end; couple the swivel joint (M) on the other end and on the telescopic bar using the front axle (N) of the extension bar.

Couple the drawbar (O) to the front part of the telescopic bar (E) using the axle lock (P) of the drawbar.

Then, couple the three-point hitch (Q) to the drawbar (O) using the axle (R) of the hitch and cotter pin.


Lastly, fasten the tool box (S) to the extension bar (K) and also fasten the water reservoir (T) to the telescopic bar (E).



Swivel joint detail (M)

Assembly


Hoppers assembly



Seed hopper

Assemble the hoppers support (A) to the support (B) using bolts, flat washers, spring washers and nuts.

Assemble the platform support (C) to the support (A) and to the handrail (E) using a bolt (F), spring washer and nut; fasten the platform (D) to the platform support (C) with a bolt (G), spacing bushing, flat washer, spring washer and nut.



Central seed hopper

Assemble the hoppers support (H) to the frame (I) using bolts, spring washers and nuts.

Assemble the ladder support (J) to the support (H) using bolts (K), spring washers and nuts.


Assembly

Ladder assembly

The ladder is positioned on the lateral, with anti-skid steps and free access to the platform, according to the NR12 standard.

Fasten the ladder (A) to the equipment lateral using bolts (B), spring washers and nuts.

Fasten the platform aisle (found inside the components box) (C) to the platform support using the same bolts that hold up the handrail.



Assembly

Row marker assembly

The row markers leave the factory unassembled and inside the components box. To assemble them, follow the instructions below.

Fasten the marker support (A) to the frame lateral (B) using bolts (C), spring washers and nuts.

Then, fasten the bar (D) to the support (A) using a pin (E), castle nut and cotter pin.

Fasten the arm (F) to the bar using a pin (G), castle nut and cotter pin.

Then, fasten the lever (H) to the support (A) and to the arm (F) using a pin (I) and cotter pin.


Couple the extensor (J) to the arm (F) using a shim (K) and locking with bolts (L) and nuts.

Lastly, lock the hydraulic cylinder (M) to the support (A) and to the bar (D) using a pin (N), flat washer and cotter pin.

Couple the pin (O) and cotter pin to the bar (D).

NOTE The transport lock (P), which can be found inside the components box, is used only when transporting the equipment.

It must be removed when the equipment is working.




Assembly

Row marker assembly

Fasten the row marker support (A) to the frame (B) using bolts (C), spring washers and nuts. Then, lock the arm (D) to the marker support using an axle (E), castle nut and cotter pin.

Fasten the cylinder (F) to the arm and to the marker support using the axle (G), flat washers and cotter pins. Then, lock the intermediate arm (H) to the arm using the axle (I), castle nut and cotter pin. Lock the intermediate arm to the marker arm (J) using the axle (I), castle nut and cotter pin.

Assemble the smaller lever (K), the rod (L) and the greater lever (M) to the intermediate arm and to the marker support using a pin (N) and cotter pin. Lastly, assemble the extensor (O) and the marker disc (P) using the bolts (Q) and arm guide (R).



Assembly


Row marker assembly

Fasten the marker support (A) to the frame lateral (B) using bolts (C), spring washers and nuts.

Lock the cylinder (D) with the axle (E), flat washers and cotter pins. Then, fasten the bar (F) to the intermediate arm (G) and to the marker support (A) using axles (H), castle nut and cotter pin.

Assemble the smaller lever (I) and the adjustable rod (J). Assemble the greater lever (K) to the intermediate arm (G) and to the support (A) using a pin (L) and cotter pin.

Lock the arm (M) to the intermediate arm (G) using an axle (H), castle nut and cotter pin. Right after, assemble the extensor (N) along with the disc blade to the arm (M) and lock using clamps (O), spring washers and nuts.




NOTE The transport lock (P), which can be found on the components box, is used only when transporting the equipment.

It must be removed when the equipment is working.

Assembly


Optimization control valve BLFP 2866 (Fluid Power)



Acronym	Description
DES	Descent movement
ADE	Right articulation pressure
AEE	Left articulation pressure
CD	Central right
CAE	Drawbar pressure
CAH	Drawbar return
CE	Central left

Acronym	Description
AEH	Left/right articulation return
LD	Right lateral
LE	Left lateral
B	Tractor pressure
A	Tractor return
TR	Lock return
TP	Lock pressure

Optimization control valve BMH 1657 (Argo Hytos)




Acronym	Description
LE	Left lateral
CE	Central left
CP	Drawbar pressure
CR	Drawbar return
RT	Lock return
RA	Articulation return
DES	Descent movement

Acronym	Description
PAE	Left articulation pressure
PAD	Right articulation pressure
PT	Lock pressure
LD	Right lateral
CD	Central right
B	Control valve pressure
A	Control valve return

Assembly

USAP hydraulic circuit with 2 Precision Planting turbines



NOTE 2014 series hydraulic circuit.

Assembly


USAP hydraulic circuit with 2 Precision Planting turbines

Item	2 Precision Planting turbines	Qty.
01	Control valve with nipple	01
02	"T" terminal	01
03	Precision planting turbine	02
04	Male quick coupler 1/2 NPT	02
05	1/2 X 3200 TR-TM hose	01 Pressure
06	1/2 X 3200 TR-TM hose	01 Return
07	3/8 X 3200 TR-TR hose	01 Drain
08	1/2 X 2300 TR-TC hose	02 Pressure
09	1/2 X 2300 TR-TC hose	02 Return
10	3/8 X 2300 TR-TC hose	02 Drain
11	1/2 X 1350 TR-TC hose	02 Pressure
12	1/2 X 1200 TR-TR hose	02 Return
13	3/8 X 1300 TR-TC hose	02 Drain

NOTE 2014 series hydraulic circuit.

Assembly

USAP hydraulic circuit with 2 Precision Planting turbines




Assembly

USAP hydraulic circuit with 2 Precision Planting turbines

Item	2 Precision planting turbines	Qty.
01	BLFP flow divider control valve	01
02	"T" terminal	01
03	Precision planting turbine	02
04	Male quick coupler 1/2 NPT	02
05	1/2 X 3200 TR-TM hose	01 Pressure
06	1/2 X 3200 TR-TM hose	01 Return
07	3/8 X 3200 TR-TR hose	01 Drain
08	1/2 X 2300 TR-TC hose	02 Pressure
09	1/2 X 2300 TR-TC hose	02 Return
10	3/8 X 2300 TR-TC hose	02 Drain
11	1/2 X 1350 TR-TC hose	02 Pressure
12	1/2 X 1200 TR-TR hose	02 Return
13	3/8 X 1300 TR-TC hose	02 Drain

Assembly

USAP hydraulic circuit with 3 Precision Planting turbines




Assembly

USAP hydraulic circuit with 3 Precision Planting turbines

Item	3 Precision planting turbines	Qty.
01	BLFP flow divider control valve	01
02	"T" terminal	01
03	Precision planting turbine	03
04	Male quick coupler 1/2 NPT	02
05	3/4 X 3300 TR-TM hose	01
06	3/4 X 3300 TR-TM hose	01
07	3/8 X 3200 TR-TR hose	01
08	1/2 X 2200 TR-TR hose	01
09	1/2 X 2200 TR-TC hose	01
10	3/8 X 2300 TR-TC hose	02
11	1/2 X 2200 TR-TC hose	02
12	1/2 X 2200 TR-TR hose	01
13	1/2 X 2200 TR-TC hose	01
14	1/2 X 2900 TR-TR hose	02
15	1/2 X 2900 TR-TR hose	02
16	3/8 X 1800 TR-TR hose	02
17	1/2 X 650 TR-TC hose	02
18	1/2 X 400 TR-TC hose	02
19	3/8 X 500 TR-TC hose	02
20	1/2 X 1550 TC-TC hose	01
21	1/2 X 1550 TC-TC hose	01
22	3/8 x 1550 TC-TC hose	01
23	3/8 x 2800 TR-TR hose	01

Assembly

USAP hydraulic circuit with 2 PP turbines and 1 CSH TATU turbine



NOTE 2014 series hydraulic circuit.

Assembly


USAP hydraulic circuit with 2 PP turbines and 1 CSH TATU turbine

Item	PP and TATU turbine	Qty.
01	Control valve with nipple	01
02	"T" terminal	01
03	"T" adapter with lateral nut	01
04	Precision planting turbine	02
05	TATU hydraulic turbine	01
06	Male quick coupler 1/2 NPT	04
07	1/2 X 3200 TR-TM hose	01 Pressure
08	1/2 X 3200 TR-TM hose	01 Return
09	1/2 X 5900 TR-TM hose	01 Pressure
10	1/2 X 5900 TR-TM hose	01 Return
11	3/8 X 3200 TR-TR hose	01 Drain
12	1/2 X 2550 TR-TC hose	02 Pressure
13	1/2 X 2550 TR-TC hose	02 Return
14	3/8 X 2550 TR-TR hose	02 Drain
15	1/2 X 2200 TR-TC hose	02 Pressure
16	1/2 X 2000 TR-TR hose	02 Return
17	3/8 X 500 TR-TC hose	01 Drain
18	1/2 X 1000 TC-TC hose	01 Pressure
19	1/2 X 1000 TC-TC hose	01 Return
20	3/8 X 900 TC-TC hose	02 Drain

NOTE 2014 series hydraulic circuit.

Assembly

USAP hydraulic circuit with 2 PP turbines and 1 CSH TATU turbine




Assembly

USAP hydraulic circuit with 2 PP turbines and 1 CSH TATU turbine

Item	PP and TATU turbines	Qty.
01	BLFP flow divider control valve	01
02	"T" terminal	01
03	"T" adapter with lateral nut	01
04	Precision planting turbine	02
05	TATU hydraulic turbine	01
06	Male quick coupler 1/2 NPT	04
07	1/2 X 3200 TR-TM hose	01
08	1/2 X 3200 TR-TM hose	01
09	1/2 X 5900 TR-TM hose	01
10	1/2 X 5900 TR-TM hose	01
11	3/8 X 3200 TR-TR hose	01
12	1/2 X 2550 TR-TC hose	02
13	1/2 X 2550 TR-TC hose	02
14	3/8 X 2550 TR-TR hose	02
15	1/2 X 2200 TR-TC hose	02
16	1/2 X 2000 TR-TR hose	02
17	3/8 X 500 TR-TC hose	01
18	1/2 X 1000 TC-TC hose	01
19	1/2 X 1000 TC-TC hose	01
20	3/8 X 900 TC-TC hose	02

Assembly

USAP hydraulic circuit with 3 PP turbines and 1 CSH TATU turbine




Assembly

USAP hydraulic circuit with 3 PP turbines and 1 CSH TATU turbine

Item	PP and TATU turbine	Qty.		Item	PP and TATU turbine	Qty.	
01	BLFP flow divider control valve	01		16	3/8 X 1800 TR-TR hose	02	Drain
02	"T" terminal	01		17	1/2 X 1800 TR-TR hose	03	Pressure
03	PP turbine	03		18	1/2 X 2900 TR-TR hose	01	Pressure
04	TATU hydraulic turbine	01		19	3/8 X 700 TR-TC hose	02	Drain
05	Male quick coupler 1/2 NPT	03		20	1/2 X 650 TR-TC hose	02	Pressure
06	3/4 X 3300 TR-TM hose	01	Pressure	21	1/2 X 550 TR-TR hose	02	Return
07	3/4 X 3300 TR-TM hose	01	Return	22	3/8 X 900 TC-TC hose	01	Drain
08	3/8 X 3200 TR-TR hose	01	Drain	23	1/2 X 1000 TC-TC hose	01	Return
09	1/2 X 5900 TR-TM hose	01	Pressure	24	1/2 X 1000 TC-TC hose	01	Pressure
10	1/2 X 2200 TR-TC hose	02	Return	25	1/2 X 2900 TR-TR hose	01	Return
11	3/8 X 2300 TR-TC hose	02	Drain	26	3/8 X 1550 TC-TC hose	02	Drain
12	1/2 X 2200 TR-TR hose	01	Pressure	27	1/2 X 1800 TR-TR hose	02	Pressure
13	1/2 X 2200 TR-TR hose	01	Return	28	1/2 X 1400 TC-TC hose	02	Return
14	1/2 X 2200 TR-TC hose	02	Pressure				
15	1/2 X 1800 TR-TR hose	02	Return				

Assembly

USAP hydraulic circuit with 3 PP turbines and 2 CSH TATU turbines




Assembly

USAP hydraulic circuit with 3 PP turbines and 2 CSH TATU turbines

Item	PP and TATU turbine	Qty.		PP and TATU turbine	Qty.		
01	BLFP flow divider control valve	02		26	1/2 X 650 TR-TC hose	01	Pressure
02	"T" terminal	01		27	1/2 X 550 TR-TR hose	01	Return
03	PP turbine	03		28	1/2 X 700 TR-TC hose	01	Drain
04	TATU hydraulic turbine	02		29	1/2 X 1000 TC-TC hose	01	Pressure
05	Male quick coupler 1/2 NPT	05		30	1/2 X 1000 TC-TC hose	01	Return
06	3/4 X 3200 TR-TM hose	01	Pressure	31	3/8 X 900 TC-TC hose	01	Drain
07	3/4 X 3200 TR-TM hose	01	Return	32	1/2 X 2900 TR-TR hose	01	Pressure
08	3/8 X 3200 TR-TM hose	01	Drain	33	1/2 X 1550 TC-TC hose	02	Pressure
09	3/4 X 3200 TR-TM hose	01	Pressure	34	1/2 X 1400 TC-TC hose	02	Return
10	3/4 X 3200 TR-TM hose	01	Return	35	3/8 X 1550 TC-TC hose	02	Drain
11	3/8 X 2550 TR-TC hose	01	Drain	36	1/2 X 700 TR-TR hose	01	Return
12	1/2 X 2550 TR-TC hose	01	Pressure	37	3/8 X 700 TR-TR hose	01	Drain
13	1/2 X 2550 TR-TC hose	01	Return	38	1/2 X 1800 TR-TR hose	01	Pressure
14	1/2 X 2550 TR-TC hose	01	Pressure	39	1/2 X 1800 TR-TR hose	01	Return
15	1/2 X 2550 TR-TC hose	01	Return	40	1/2 X 1800 TR-TR hose	01	Pressure
16	3/8 X 2550 TR-TC hose	01	Drain	41	1/2 X 1800 TR-TR hose	01	Return
17	1/2 X 2550 TR-TC hose	01	Pressure	42	1/2 X 1800 TR-TR hose	01	Return
18	1/2 X 2550 TR-TC hose	01	Return	43	3/8 X 1800 TR-TC hose	01	Drain
19	1/2 X 2550 TR-TC hose	01	Pressure	44	1/2 X 1000 TC-TC hose	01	Pressure
20	1/2 X 2550 TR-TC hose	01	Return	45	1/2 X 1000 TC-TC hose	01	Return
21	3/8 X 1800 TR-TR hose	01	Drain	46	3/8 X 1000 TC-TC hose	01	Drain
22	1/2 X 1800 TR-TR hose	01	Pressure	47	1/2 X 2550 TR-TR hose	01	Pressure
23	1/2 X 1800 TR-TR hose	01	Return	48	1/2 X 2550 TR-TR hose	01	Return
24	1/2 X 1800 TR-TR hose	01	Pressure				
25	1/2 X 550 TR-TR hose	01	Return				

Assembly

Wheelset hydraulic circuit




Assembly

Wheelset hydraulic circuit

Item	USAP wheelset	Qty.
01	BLFP 2604 control valve	01
03	Hydraulic cylinder	08
04	Male quick coupler 1/2 NPT	02
05	3/4 X 5900 TR-TM hose	01
06	3/4 X 5900 TR-TM hose	01
07	3/4 X 2750 TR-TR hose	01
08	3/4 X 2750 TR-TR hose	01
09	3/4 X 1250 TR-TR hose	01
10	3/4 X 1250 TR-TR hose	01
11	3/8 X 1800 TR-TC hose	01
12	3/8 X 1100 TR-TC hose	02
13	3/8 X 1700 TR-TC hose	01
14	3/4 X 950 TR-TC hose	01
15	3/8 X 700 TR-TR hose	02
16	3/8 X 700 TR-TR hose	02
17	3/8 X 700 TR-TC hose	02
18	3/8 X 700 TR-TC hose	02
19	3/8 X 650 TC-TC hose	02
20	3/8 X 650 TC-TC hose	02
21	3/8 X 900 TR-TC hose	03
22	3/8 X 1000 TR-TC hose	01
23	3/8 X 750 TC-TC hose	01
24	3/8 X 1000 TC-TC hose	02
25	3/8 X 900 TC-TC hose	01
26	3/8 X 900 TR-TC hose	01
27	3/8 X 1100 TR-TC hose	01

Assembly


Articulation hydraulic circuit



Item	USAP articulation	Qty.
01	Optimization control valve	01
02	"T" adapter with lateral nut	01
03	Nipple 3/4" UNF	04
04	Articulation hydraulic cylinder	02
05	Hydraulic cylinder with telescopic lock	01
06	3/8 X 1400 TC-TC hose	01
07	3/8 X 2000 TR-TC hose	01
08	3/8 X 1200 TC-TC hose	01
09	3/8 X 1800 TC-TC hose	01
10	3/8 X 1300 TC-TC hose	01
11	3/8 X 1500 TC-TC hose	01

Assembly


Drawbar articulation hydraulic circuit



Item	USAP drawbar articulation	Qty.
01	Optimization control valve	01
02	Hydraulic cylinder	01
03	3/8 X 1600 TR-TC hose	01
04	3/8 X 1600 TR-TC hose	01
05	3/8 X 2800 TR-TR hose	01
06	3/8 X 2800 TR-TR hose	01
07	3/8 X 2900 TR-TC hose	01
08	3/8 X 3200 TR-TC hose	01

Assembly

Row marker hydraulic circuit




Assembly

Row marker hydraulic circuit

Item	USAP row marker	Qty.
01	Complete sequence valve	01
02	Hydraulic cylinder	02
03	Male quick coupler 1/2 NPT	02
04	3/8 X 5850 TR-TM hose	01
05	3/8 X 5850 TR-TM hose	01
06	3/8 X 2800 TR-TR hose	01
07	3/8 X 2800 TR-TR hose	01
08	3/8 X 1500 TC-TC hose	01
09	3/8 X 1500 TC-TC hose	01
10	3/8 X 1400 TR-TC hose	02
11	3/8 X 1400 TR-TC hose	02
12	3/8 X 700 TR-TR hose	02
13	3/8 X 700 TR-TR hose	02
14	3/8 X 1600 TR-TC hose	02
15	3/8 X 1300 TR TC hose	02

Assembly

APT hydraulic circuit




Assembly

APT hydraulic circuit

Item	APT USAP	Qty.
01	Flow rate limiter control valve	01
02	Filter with gauge	01
03	OMP 80 hydraulic motor with valve	03
04	APT motor support	03
05	Male quick coupler 1/2 NPT	02
06	1/2 X 5900 TR-TM hose	01
07	1/2 X 5900 TR-TM hose	01
08	1/2 X 2100 TR-TC hose	01
09	1/2 X 1900 TR-TR hose	01
10	1/2 X 400 TR-TC hose	01
11	1/2 X 1200 TR-TC hose	01
12	1/2 X 1000 TC-TC hose	01
13	1/2 X 2800 TC-TC hose	01
14	1/2 X 1200 TR-TC hose	01
15	1/2 X 1700 TC-TC hose	01
16	1/2 X 1200 TR-TC hose	01
17	1/2 X 2000 TC-TC hose	01
18	1/2 X 1200 TR-TC hose	01

Assembly

USAP electric system assembly (with clutch)



NOTE When the button is pressed and the light is off, the system is not working.


Assembly

Lifting sensor

The lifting sensor (A) automatically turns on or off the seed distribution by lifting the equipment and when it is lowered, the seeds start to being released again.

Fasten the retrieving mechanism (B) to the wheelset fork (C) using bolts, spring washers and nuts.

Then, fasten the sensor support (D) to the wheelset support (E) using bolts, flat washers, spring washers and nuts.




Assembly

Seed row unit with disc blade (mechanical)

Lock the rear part of the row unit (A) to the parallelogram (B) using bolts (C), spring washers and nuts. Then, fasten the depth control (D) using bolts (E), spring washers and nuts. Then, lock the hopper (F) with fastener (G).

To avoid damages to the fastener and the seed disc blade locking, never tighten the fastener adjustment (H) totally; leave it facing the threaded stud (I).

Lastly, lock the disc blade (J) to the parallelogram (B) using a bolt (K) and nut.



For a long row unit with a spacing of 450 mm, always use the depth control with an extensor of 230 (L) for a displacement of 40 mm.

Assembly

Seed row unit with disc blade (Titanium)

The seed row unit leaves the factory assembled, being only necessary to fix some items.

Fix the depth control (A) to the unaligned double disc (B) using bolts (C), spring washers and nuts.


Then, fasten the double disc (B) on the front of the row unit (D) using bolts (E), spring washers and nuts.

Couple the hexagonal axle (F) to the double disc (B).

Lock the Titanium seed metering (G) to the double disc (B) with the fastener (H).

To avoid damages to the fastener and the seed disc blade locking, never tighten the fastener adjustment (I) totally; leave it facing the threaded stud (J).

Lastly, lock the disc blade (K) to the parallelogram (D) using bolts (L) and nut.



Assembly

Seed row unit with disc blade (Precision Planting)

The seed row unit leaves the factory assembled, being only necessary to fix some items.


Fix the depth control (A) to the unaligned double disc (B) using bolts (C), spring washers and nuts.

Then, fasten the double disc (B) to the front part of the row unit (D) using bolts (E), spring washers and nuts.

Couple the hexagonal axle (F) to the Precision Planting seed metering (G).

Lock the metering (G) to the double disc (B) along with the seed tube (H) using a bolt (I), spring washer and nut.

Lastly, lock the disc blade (J) to the parallelogram (D) using bolts (K) and nut.



Assembly

Seed row unit with disc blade (Vdrive)

The rear part of the row unit leaves the factory assembled, being only necessary to fix some items.


Fix the depth control (A) to the unaligned double disc (B) using bolts (C), spring washers and nuts.

Then, fasten the rear part of the row unit to the front part (D) using bolts (E), spring washers and nuts.

Couple the Vdrive system (F) to the Precision Planting seed metering.

Fasten the hopper (G) to the Precision Planting seed metering.

Lastly, lock the disc blade (H) to the parallelogram (D) using bolts (I) and nut.




Assembly

Hose assembly on the seed hoppers

To assemble the hoses on the seed hoppers, proceed as follows:

- 1) Totally lift the planter until the upper arm touch the shock absorber.
- 2) Place the seed tube (A) with clamps (B) on the greater seed hopper (C).
- 3) Secure the seed tube (A) on the smaller seed hopper (D) using the clamp (E).
- 4) Lastly, fasten the support guide (F) of the seed tube on the support (G) to avoid that the seed tube escape from the seed hoppers. Repeat this operation on every row unit.




Assembly

Hose assembly on the fertilizer hoppers

To assemble the hoses on the fertilizer hoppers, proceed as follows:

- 1) Place the fertilizer hose (A) with clamps (B) on the greater fertilizer hopper (C).
- 2) Lock the fertilizer hose (A) on the fertilizer tube (D) using the clamp (B).
- 3) Lastly, secure the clamp (E) with a spring washer and nut to avoid its movement on the frame.



Set-up instructions

Tractor preparation

If necessary, use counterweights on the frontal part of the tractor.

Hitching to the tractor

Choose a place as flat as possible for hitching.



Drive the tractor slowly in reverse gear to reach the equipment and be ready to apply the brakes. When close enough, use the lever to control the hydraulic position and let the left lower arm on the same level as the equipment hitch pin.

1) Hitch the right and left arms that have ascent and descent movements through the lower arm adjustment and place the lock pins. At this moment, the extensor thread of the upper arm can be used to approach or move away the equipment, thus facilitating the hitching.

2) Place the upper arm (third point) and fasten it using a lock pin.

For a perfect hitching, the equipment must be centralized with the tractor, which is done as follows:

- Align the equipment drawbar with the third point of the tractor.
- Totally lift the equipment.
- Check if the distances between the lower arms and tires are equal on both sides (as in "A"), being them leveled (as in "B").




- Couple the hoses to the tractor quick couplers with double command. There are two hoses to lift or lower the equipment and two to activate the row marker cylinders.

Set-up instructions

Hitching to the tractor

When the equipment is already leveled and coupled to the tractor third point and before starting planting, it is necessary to adjust the tractor hitch bar (A) on the center of the third point drawbar between the plates (B) and lock using a pin (C) and cotter pin.

This procedure will prevent damages to the equipment.



Note that the drawbar (D) has holes so that the equipment can work with several tractor models.

NOTE


Do not activate the tractor third point when the hitch bar is locked on the drawbar, otherwise there may be damages on the rear part of the tractor.

To transport the equipment, remove the pin (C) from the hitch bar.

Planter leveling

Level the equipment through the upper arm of the third point.

To facilitate the upper arm usage, activate the hydraulic cylinder to relieve the drawbar on the hitch bar.




Set-up instructions



Setting the planter to transport position

After hitching the equipment, totally lift the row units by activating the hydraulic cylinder.



Place the safety locks (A) on the hydraulic cylinder rods located on the central wheelset of the central frame and hydraulic row markers.



Fold the planter, lift the third point of the equipment and articulate the lateral wheelsets (B).



To transport the equipment, use the lock (C), so the seed row unit will stay in an elevated position to avoid irregular terrains.



Set-up instructions

Setting the planter to transport position


The equipment has articulation cylinders that helps to fold the planter.

To make the planter moves in the folding direction, activate the wheelset circuit to let the planter suspended and then activate the hydraulic circuit of the articulation. When the circuit is activated the lock of the telescopic bar will be lifted first, so unlock it to release the lateral cylinders and they will start to fold, thus moving the lateral frames to the greater lock (A) direction.

When the equipment is folding, the operator must drive the tractor forward on a compatible speed to help the folding process until the operation is concluded.

After hitching the equipment on the greater lock, lift the lateral wheelsets.

To unfold the planter, do the procedures in reverse order.



ATTENTION

Never transport or store the planter when the reservoir is full, as this may cause damages to the equipment.


Maximum transportation speed: 15 km/h.

Set-up instructions

Spacing between row units


The USAP planter leaves the factory with a minimum row spacing according to the requested number of row units, allowing a possibility of other spacing if the crop needs it.

Positioning the row units on the frame



Even number of row units:

Set the frame center and measure half of a spacing to the right and half to the left, placing on these points the first two row units; from these rows, set the other ones with one spacing to each side.



Odd number of row units:

Place one row unit in the frame center and set the other ones with the desired spacing.

NOTE

See all the possible spacings on the next pages, following the example of these illustrations.

For the long row units with a spacing of 450 mm, use extensors of 230 mm to have a displacement of 40 mm.

Set-up instructions

Spacing tables

See every possible spacing on the table below.

Number of row units	Spacing (mm)
18	450, 500, 550
20	450, 500, 550
22	450, 500, 550
24	450, 500, 550
25	450, 500, 550
26	450, 500, 550
27	450, 500, 550
28	450, 500, 550
29	450, 500, 550
30	450, 500, 550
32	450, 500, 550
33	450, 500, 550
35	450, 500, 550
36	450, 500, 550
40	450, 500, 550
42	450, 500, 550
45	450, 500, 550
46	450, 500, 550
50	450, 500, 550


Set-up instructions

Procedures to change the spacing

To change the spacing, lift the equipment with the help of the wheelsets and underpin them to avoid accidents.

- Loosen up the bolt (A) of the clamp on the seed row unit.
- Remove the bushing (B) of the axle lock of the transmission by loosening up the bolt.
- Remove the seed hose (C) from the seed row unit.
- Release the clamp (D) that fasten the fertilizer tube.
- Remove the hose (E) from the fertilizer hopper.

Then, move the seed and fertilizer row unit by following the table on the page (68).




Set-up instructions

IMPORTANT

Retighten all sets, paying attention to the following points:

- Retighten the nuts that fasten the seed rows on the frame gradually, avoiding to totally tighten each nut at a time.
- That information is also useful between a row unit and another. So, do not totally tighten a row unit at a time, but gradually.
- When switching between this nut tightening operation of a row unit and passing to another, it is necessary to spin the hexagonal axle to keep the proper alignment and avoid locking.
- The tightening of the bearings that fasten the hexagonal axle should be done in the end.
- Check the correct alignment of the chains (clutches / wheelsets).

- To close the fertilizer outlet, place the chutes (A) over the augers that will not be used.



To work with some of the row units lifted, you must:

- Remove all the rear part of the row units;
- Remove the traction spring;
- Release the frontal part of the upper rocker arm;
- Lift the row unit and lock it using the upper rocker arm;
- Remove the fertilizer tube from the fertilizer row unit.

Set-up instructions

Filling up the planter

With the aid of a hoist and a Big-bag, fill up the central seed hoppers as shown below.

Approach the tractor to a safe distance from the planter and use the lateral ladders and the central one to have access to the platforms when filling up the planter.



ATTENTION

When filling up the planter, be careful to not stay under the Big-bag.
Keep a distance to manipulate the Big-bag safely.

Set-up instructions

Planning the plantation - Correct seed rate


Consider that the amount of plants in the harvest is always smaller than the number of seeds distributed in the planting operation, due to the following factors: germination rate, physical purity, vigor (provided in the seed pack), plagues and diseases that may take place during the cultivation cycle.

Also, consider that during the plantation slippage or skidding of the planter tires can occur, according to the local working conditions.


How to calculate the slippage index of the planter:

This index is obtained by comparing the number of spins the tire will perform, being the planter with empty hoppers and then filling it up, moving the planter around to see the difference.

Being the planter empty and normally hitched to the tractor, set a starting point on the ground and on the tire. Move the planter until the tire complete 10 (ten) spins. Measure and write down the traveled distance.



Fill up the planter hopper, repeat the previous procedure and write down the traveled distance.



Calculation:

$$\frac{\text{Distance with load} - \text{Distance without load} \times 100}{\text{Distance without load}}$$

NOTE

The tires must have the same design, same inflation and same adjustment of springs over the wheelset arms.

Set-up instructions

Calculation of seeds per hectare

To obtain an amount of 50,000 plants per hectare in the cultivation, whose seeds contain:

Germination index = 95%

Physical purity = 90

Slippage index = 1.03 (3%)

The following calculation should be made to know how many seeds should be distributed in a hectare.

Seeds/ha in the plantation = $0.95 \times 0.90 = 0.855$

$\underline{50,000} = 58,479.53 \times 1.03 = \underline{\mathbf{60,233.91}}$

0.855

To know the amount of seeds per meter, per 10 meters and so on, calculate how many linear meters of rows exist in a hectare, in the desired spacing.

Example: $\frac{10,000}{0.85 \text{ m}} = 11,764.70$ linear meters, so: $\frac{60,233.91}{11.764,7} = \underline{\mathbf{5.1198}}$

Approximately **5.12** seeds per meter.

Procedures before the plantation

- Before starting the plantation, make a general inspection of the equipment. Retighten all bolts and nuts and check the condition of all pins and cotter pins, avoiding future damages. Repeat this operation after the first day of work.
- Check the tires inflation and keep all tires with the same pressure. Check the correct pressure on page **129**.
- Also check if there is no strange object inside the hoppers, which may damage the metering mechanisms.
- Lubricate all grease fitting appropriately.

NOTE

- Only fill up the planter on the work station.
- Do not pull the planter with load excess.

Ideal working speed

USAP works with higher efficiency from 5 to 7 Km/h.

To transport the planter, the speed must not exceed 15 km/h.

NOTE

- When planting corn, operate from 5 to 5.5 km/h.
- Keep a constant speed during the whole job.

Set-up instructions

Graphite powder use

The graphite powder should be combined to the seeds to facilitate the distribution and to increase the lifetime of the metering device.

Amount of graphite per kilogram of seed			
Planter distribution system:	Seeds treated with insecticide		
	Small and round	Big and round	Flattened
Horizontal seed plates	04 grams	02 grams	04 grams

- The graphite should not be combined before the seed treatment.
- The graphite should not be combined to the insecticide to apply in the seeds.
- For non-treated seeds, use only half of the graphite mentioned in the previous table.

NOTE

The seed metering feature buttons, rocker arm and pulley. They must be cleaned internally at least once a day for the plantation of non-treated seeds and twice a day for the plantation of treated seeds.

List of standard seed plates in the planter

Description	Serial number
Ø 9 mm soybean seed plate (pink)	05.03.01.6218
Ø 12 mm corn seed plate (orange)	05.03.01.6204

Optional seed plates list on page 102.

ATTENTION

The amount of seed plates that are included with the planter corresponds to the number of row units.



NOTE

- The available height for the placement of the plate plus the false ring is 8.5 mm, however:
 - If a plate has a thickness of 4.5 mm, the false ring must have 4 mm.
 - To use a plate that has a thickness of 5.5 mm, place a false ring of 3 mm.
 - Do not put a false ring if a plate that has 8.5 mm of thickness is used.





Set-up instructions



- Special attention should be given to the rocker arm and seed sprocket, as well as the good operation of all seed meterings.
- The rocker arm and the pulley of 5 teeth goes assembled with the equipment and can be used in all places with one row of slots or holes, i.e.: corn in round shape, soybean, delinted cotton, bean and others.
- For the plate for corn with oblong holes use the pulley with 4 teeth, which is not included with the equipment.



- For planting sorghum, it is necessary to use special pulleys, so that they enter in the holes and execute their function.



- For the soybean plate that features a double row of holes, it is necessary to use the double rocker arm (with two pulleys).



Adjustments and operations

Seeds distribution

Gearbox (mechanical and pneumatic) to distribute the seeds.

The amount and size of the holes/slots and the thickness of the seed plates can vary according to the grain size and the desired plant amount.

Adjust the seed rate per linear meter through the sprocket combinations of the Drive shaft **{A}** (14, 18, 22, 26, 30, 34 and 38 teeth) and Driven shaft **{B}** (14,18, 22, 26, 30, 34 and 38 teeth).


ATTENTION The procedure to change the sprockets to either the mechanical and pneumatic system is the same.

Procedures to change the sprockets

Move the lever to relieve the chain tightener and lock it using the pin.

Manually displace the set of sprockets in the shaft and align the chosen sprocket with the chain.

Release the lever to loose the lock pin.



NOTE


- The cone bolts (C) on the sprocket handling "TRA" are pre-adjusted on the factory, allowing to change the sprockets without using any tool.
- In case of any sliding motion on the cone shaft, just release the counter nut and turn around the bolt to re-lock.
- In order to avoid damage to the spring and shafts, never apply excessive torque when tightening.

Adjustments and operations

Procedures to change the sprockets

RECÂMBIO DE ENGRANAGENS SPROCKET COMBINATIONS CAMBIO DE ENGRANAJES


SEMENTE SEEDS SEMILLAS



05.03.03.2986

RECÂMBIO DE ENGRANAGENS SPROCKET COMBINATIONS CAMBIO DE ENGRANAJES

SEMENTE SEEDS SEMILLAS



05.03.03.2987

IMPORTANT

The following pages show the different amount of fertilizer distributed using several spacings, according to the sprocket combinations.

The correct seed plate matching to the used seeds is very important.
Never combine seeds of different sizes.

The seed and fertilizer distribution tables in this manual must be used as a reference to start the planter adjustment. Factors such as the slippage index of the planter wheels (skidding), working speed, tire inflation, field conditions, seed type and others can make the values differ from the ones in the table. Therefore, it is always indispensable to make the practical distribution tests, as indicated on page 86.

Adjustments and operations

Mechanical seeds distribution table - (tire Ø 831/ 921)

Check how to calculate the amount of seed using the example on page 82.

Tires list according to the table below:

Central frame:- 14 x 17.5/14 TR SK 900 tire (Ø 921);

Lateral frame:- 12 x 16.5/12 L TR SK 900 tire (Ø 831)

**TABELA DE DISTRIBUIÇÃO DE SEMENTES
TABLE FOR DISTRIBUTION OF SEEDS
TABLA DE DISTRIBUCIÓN DE SEMILLAS**

Número de Furos Number of Holes Número de Agujeros		24	28	34	38	40	62	64	90	94	100
Engrenagens / Sprockets / Engranajes	Eixo Motor Drive Shaft Eje Motor	Sementes em 1 Metro Linear / Seeds in 1 Linear Meter / Semillas en 1 Metro Lineal									
Eixo Movido Driven Shaft Eje Movido		1,41	1,65	2,00	2,24	2,36	3,65	3,77	5,31	5,54	5,89
14	38	1,41	1,65	2,00	2,24	2,36	3,65	3,77	5,31	5,54	5,89
14	34	1,58	1,84	2,24	2,50	2,64	4,08	4,22	5,93	6,19	6,59
14	30	1,79	2,09	2,54	2,84	2,99	4,63	4,78	6,72	7,02	7,74
18	38	1,82	2,12	2,58	2,88	3,03	4,70	4,85	6,82	7,12	7,58
18	34	2,03	2,37	2,88	3,22	3,39	5,25	5,42	7,62	7,96	8,47
14	26	2,07	2,41	2,93	3,27	3,45	5,34	5,51	7,75	8,10	8,62
22	38	2,22	2,59	3,15	3,52	3,71	5,74	5,93	8,34	8,71	9,26
18	30	2,30	2,69	3,26	3,65	3,84	5,95	6,14	8,64	9,02	9,60
14	22	2,44	2,85	3,46	3,87	4,07	6,31	6,52	9,16	9,57	10,18
22	34	2,48	2,90	3,52	3,93	4,14	6,42	6,63	9,32	9,73	10,35
26	38	2,63	3,07	3,72	4,16	4,38	6,79	7,01	9,85	10,29	10,95
18	26	2,66	3,10	3,77	4,21	4,43	6,87	7,09	9,97	10,41	11,08
22	30	2,82	3,29	3,99	4,46	4,69	7,27	7,51	10,56	11,03	11,73
26	34	2,94	3,43	4,16	4,65	4,89	7,59	7,83	11,01	11,50	12,24
14	18	2,99	3,48	4,23	4,73	4,98	7,72	7,96	11,20	11,70	12,44
30	38	3,03	3,54	4,29	4,80	5,05	7,83	8,08	11,37	11,87	12,63
18	22	3,14	3,67	4,45	4,97	5,24	8,12	8,38	11,78	12,31	13,09
22	26	3,25	3,79	4,60	5,14	5,42	8,39	8,66	12,19	12,73	13,54
26	30	3,33	3,88	4,71	5,27	5,55	8,60	8,88	12,48	13,04	13,87
30	34	3,39	3,95	4,80	5,36	5,65	8,75	9,04	12,71	13,27	14,12
34	38	3,44	4,01	4,87	5,44	5,73	8,88	9,16	12,88	13,46	14,32
22	22	3,84	4,48	5,44	6,08	6,40	9,92	10,24	14,40	15,04	16,00
38	34	4,29	5,01	6,08	6,80	7,15	11,09	11,45	16,09	16,81	17,88
34	30	4,35	5,08	6,17	6,89	7,25	11,24	11,61	16,32	17,05	18,13
30	26	4,43	5,17	6,28	7,02	7,38	11,45	11,82	16,62	17,35	18,46
26	22	4,54	5,29	6,43	7,19	7,56	11,72	12,10	17,02	17,78	18,91
22	18	4,69	5,48	6,65	7,43	7,82	12,12	12,52	17,60	18,38	19,56
38	30	4,86	5,67	6,89	7,70	8,11	12,57	12,97	18,24	19,05	20,27
18	14	4,94	5,76	6,99	7,82	8,23	12,75	13,17	18,52	19,34	20,57
34	26	5,02	5,86	7,11	7,95	8,37	12,97	13,39	18,83	19,67	20,92
30	22	5,24	6,11	7,42	8,29	8,73	13,53	13,96	19,64	20,51	21,82
26	18	5,55	6,47	7,86	8,78	9,24	14,33	14,79	20,80	21,73	23,11
38	26	5,61	6,55	7,95	8,89	9,35	14,50	14,97	21,05	21,98	23,39
34	22	5,93	6,92	8,41	9,40	9,89	15,33	15,83	22,26	23,24	24,73
22	14	6,03	7,04	8,55	9,55	10,06	15,59	16,09	22,63	23,64	25,14
30	18	6,40	7,47	9,07	10,13	10,67	16,53	17,07	24,00	25,07	26,67
38	22	6,63	7,74	9,40	10,50	11,05	17,14	17,69	24,87	25,98	27,64
26	14	7,13	8,32	10,10	11,29	11,89	18,42	19,02	26,74	27,93	29,72
34	18	7,25	8,46	10,28	11,48	12,09	18,74	19,34	27,20	28,41	30,22
38	18	8,11	9,46	11,48	12,84	13,51	20,94	21,62	30,40	31,75	33,78
30	14	8,23	9,60	11,66	13,03	13,71	21,26	21,94	30,86	32,23	34,29
34	14	9,33	10,88	13,21	14,77	15,54	24,09	24,87	34,97	36,53	38,86
38	14	10,42	12,16	14,77	16,50	17,37	26,93	27,80	39,09	40,82	43,43

Sistema TATU / TITANIUM = PNEU Ø 921

* Metro Linear / Linear Meter / Metro Lineal

05.03.03.4679 - Revisão 00 - 0618

Adjustments and operations

Precision planting seeds distribution table - (tire Ø 831 / 921)

Check how to calculate the amount of seed using the example on page 82.

Tires list according to the table below:

Central frame:- 14 x 17.5/14 TR SK 900 tire (Ø 921);

Lateral frame:- 12 x 16,5/12 L TR SK 900 tire (Ø 831).

**TABELA DE DISTRIBUIÇÃO DE SEMENTES
TABLE FOR DISTRIBUTION OF SEEDS
TABLA DE DISTRIBUCIÓN DE SEMILLAS**

Número de Furos Number of Holes Número de Agujeros	27	32	39	40	70	80
Engrenagens / Sprockets / Engranajes						
Eixo Motor Drive Shaft <i>Eje Motor</i>	Eixo Móvel Driven Shaft <i>Eje Movido</i>	Sementes em 1 Metro Linear / Seeds in 1 Linear Meter / Semillas en 1 Metro Lineal				
14	38	1,59	1,89	2,30	2,36	4,13
14	34	1,78	2,11	2,57	2,64	4,61
14	30	2,02	2,39	2,91	2,99	5,23
18	38	2,05	2,43	2,96	3,03	5,31
18	34	2,29	2,71	3,30	3,39	5,93
14	26	2,33	2,76	3,36	3,45	6,03
22	38	2,50	2,96	3,61	3,71	6,48
18	30	2,59	3,07	3,74	3,84	6,72
14	22	2,75	3,26	3,97	4,07	7,13
22	34	2,80	3,31	4,04	4,14	7,25
26	38	2,96	3,50	4,27	4,38	7,66
18	26	2,99	3,54	4,32	4,43	7,75
22	30	3,17	3,75	4,58	4,69	8,21
26	34	3,30	3,92	4,77	4,89	8,57
14	18	3,36	3,98	4,85	4,98	8,71
30	38	3,41	4,04	4,93	5,05	8,84
18	22	3,53	4,19	5,11	5,24	9,16
22	26	3,66	4,33	5,28	5,42	9,48
26	30	3,74	4,44	5,41	5,55	9,71
30	34	3,81	4,52	5,51	5,65	9,88
34	38	3,87	4,58	5,58	5,73	10,02
22	22	4,32	5,12	6,24	6,40	11,20
38	34	4,83	5,72	6,97	7,15	12,52
34	30	4,90	5,80	7,07	7,25	12,69
30	26	4,98	5,91	7,20	7,38	12,92
26	22	5,11	6,05	7,37	7,56	13,24
22	18	5,28	6,26	7,63	7,82	13,69
38	30	5,47	6,49	7,90	8,11	14,19
18	14	5,55	6,58	8,02	8,23	14,40
34	26	5,65	6,70	8,16	8,37	14,65
30	22	5,89	6,98	8,51	8,73	15,27
26	18	6,24	7,40	9,01	9,24	16,18
38	26	6,31	7,48	9,12	9,35	16,37
34	22	6,68	7,91	9,64	9,89	17,31
22	14	6,79	8,05	9,81	10,06	17,60
30	18	7,20	8,53	10,40	10,67	18,67
38	22	7,46	8,84	10,78	11,05	19,35
26	14	8,02	9,51	11,59	11,89	20,80
34	18	8,16	9,67	11,79	12,09	21,16
38	18	9,12	10,81	13,17	13,51	23,65
30	14	9,26	10,97	13,37	13,71	24,00
34	14	10,49	12,43	15,15	15,54	27,20
38	14	11,73	13,90	16,94	17,37	30,40
Sistema PRECISION PLANTING - PNEU Ø 921		* Metro Linear / Linear Meter / Metro Lineal				

05.03.03.4680 - Revisão 00 - 0618

Adjustments and operations

Mechanical seed distribution table - (tire Ø 921/ 1072)

Check how to calculate the amount of seed using the example on page 82.

Tires list according to the table below:

Central frame:- 385/65 R 22.50 D 711 DRC 15-19.50 20 L tire (Ø 1072)

Lateral frame:- 14 x 17.5/14 TR SK 900 tire (Ø 921)

TABELA DE DISTRIBUIÇÃO DE SEMENTES TABLE FOR DISTRIBUTION OF SEEDS TABLA DE DISTRIBUCIÓN DE SEMILLAS												
Número de Furos Number of Holes Número de Agujeros		24	28	34	38	40	62	64	90	94	100	
Engrenagens / Sprockets / Engranajes	Eixo Motor Drive Shaft Eje Motor	Eixo Movido Driven Shaft Eje Movido	Sementes em 1 Metro Linear / Seeds in 1 Linear Meter / Semillas en 1 Metro Lineal									
14	38		1,40	1,63	1,98	2,21	2,33	3,61	3,72	5,23	5,47	5,81
14	34		1,56	1,82	2,21	2,47	2,60	4,03	4,16	5,85	6,11	6,50
14	30		1,77	2,06	2,50	2,80	2,95	4,57	4,71	6,63	6,92	7,37
18	38		1,79	2,09	2,54	2,84	2,99	4,64	4,78	6,73	7,03	7,48
18	34		2,01	2,34	2,84	3,18	3,34	5,18	5,35	7,52	7,85	8,36
14	26		2,04	2,38	2,89	3,23	3,40	5,27	5,44	7,65	7,99	8,50
22	38		2,19	2,56	3,11	3,47	3,66	5,67	5,85	8,22	8,59	9,14
18	30		2,27	2,65	3,22	3,60	3,79	5,87	6,06	8,52	8,90	9,47
14	22		2,41	2,81	3,41	3,82	4,02	6,23	6,43	9,04	9,44	10,04
22	34		2,45	2,86	3,47	3,88	4,09	6,33	6,54	9,19	9,60	10,21
26	38		2,59	3,02	3,67	4,10	4,32	6,70	6,91	9,72	10,15	10,80
18	26		2,62	3,06	3,72	4,15	4,37	6,77	6,99	9,83	10,27	10,93
22	30		2,78	3,24	3,94	4,40	4,63	7,18	7,41	10,42	10,88	11,57
26	34		2,90	3,38	4,10	4,59	4,83	7,48	7,72	10,86	11,35	12,07
14	18		2,95	3,44	4,17	4,66	4,91	7,61	7,86	11,05	11,54	12,28
30	38		2,99	3,49	4,24	4,74	4,98	7,73	7,97	11,21	11,71	12,46
18	22		3,10	3,62	4,39	4,91	5,17	8,01	8,26	11,62	12,14	12,91
22	26		3,21	3,74	4,54	5,07	5,34	8,28	8,55	12,02	12,55	13,36
26	30		3,28	3,83	4,65	5,20	5,47	8,48	8,75	12,31	12,86	13,68
30	34		3,34	3,90	4,74	5,29	5,57	8,63	8,91	12,53	13,09	13,93
34	38		3,39	3,95	4,80	5,37	5,65	8,76	9,04	12,71	13,27	14,12
22	22		3,79	4,42	5,37	6,00	6,31	9,79	10,10	14,21	14,84	15,78
38	34		4,23	4,94	6,00	6,70	7,06	10,94	11,29	15,88	16,58	17,64
34	30		4,29	5,01	6,08	6,80	7,16	11,09	11,45	16,10	16,81	17,89
30	26		4,37	5,10	6,19	6,92	7,28	11,29	11,66	16,39	17,12	18,21
26	22		4,48	5,22	6,34	7,09	7,46	11,56	11,94	16,79	17,53	18,65
22	18		4,63	5,40	6,56	7,33	7,72	11,96	12,35	17,36	18,13	19,29
38	30		4,80	5,60	6,80	7,60	8,00	12,40	12,80	17,99	18,79	19,99
18	14		4,87	5,68	6,90	7,71	8,12	12,58	12,99	18,26	19,08	20,29
34	26		4,95	5,78	7,02	7,84	8,26	12,80	13,21	18,58	19,40	20,64
30	22		5,17	6,03	7,32	8,18	8,61	13,34	13,77	19,37	20,23	21,52
26	18		5,47	6,38	7,75	8,66	9,12	14,13	14,59	20,52	21,43	22,80
38	26		5,54	6,46	7,84	8,77	9,23	14,30	14,76	20,76	21,68	23,07
34	22		5,85	6,83	8,29	9,27	9,76	15,12	15,61	21,95	22,93	24,39
22	14		5,95	6,94	8,43	9,42	9,92	15,38	15,87	22,32	23,31	24,80
30	18		6,31	7,37	8,94	10,00	10,52	16,31	16,84	23,68	24,73	26,31
38	22		6,54	7,63	9,27	10,36	10,90	16,90	17,45	24,54	25,63	27,26
26	14		7,03	8,21	9,97	11,14	11,72	18,17	18,76	26,38	27,55	29,31
34	18		7,16	8,35	10,14	11,33	11,93	18,48	19,08	26,83	28,02	29,81
38	18		8,00	9,33	11,33	12,66	13,33	20,66	21,33	29,99	31,32	33,32
30	14		8,12	9,47	11,50	12,85	13,53	20,97	21,65	30,44	31,79	33,82
34	14		9,20	10,73	13,03	14,57	15,33	23,77	24,53	34,50	36,03	38,33
38	14		10,28	12,00	14,57	16,28	17,14	26,56	27,42	38,56	40,27	42,84

Sistema TATU / TITANIUM = PNEU Ø 1072

* Metro Linear / Linear Meter / Metro Lineal

05.03.03.4681 - Revisão 00 - 0618

Adjustments and operations

Precision planting seed distribution table - (tire Ø 921/ 1072)

Check how to calculate the amount of seed using the example on page 82.

Tires list according to the table below:

Central frame:- 385/65 R 22.50 D 711 DRC 15-19.50 20 L tire (Ø 1072)

Lateral frame:- 14 x 17.5/14 TR SK 900 tire (Ø 921)

**TABELA DE DISTRIBUIÇÃO DE SEMENTES
TABLE FOR DISTRIBUTION OF SEEDS
TABLA DE DISTRIBUCIÓN DE SEMILLAS**

Número de Furos Number of Holes Número de Agujeros		27	32	39	40	70	80
Eixo Motor Drive Shaft Eje Motor	Eixo Móvel Driven Shaft Eje Movido	Sementes em 1 Metro Linear / Seeds in 1 Linear Meter / Semillas en 1 Metro Lineal					
14	38	1,57	1,86	2,27	2,33	4,07	4,65
14	34	1,75	2,08	2,53	2,60	4,55	5,20
14	30	1,99	2,36	2,87	2,95	5,16	5,89
18	38	2,02	2,39	2,92	2,99	5,23	5,98
18	34	2,26	2,67	3,26	3,34	5,85	6,68
14	26	2,29	2,72	3,31	3,40	5,95	6,80
22	38	2,47	2,92	3,56	3,66	6,40	7,31
18	30	2,56	3,03	3,69	3,79	6,63	7,58
14	22	2,71	3,21	3,92	4,02	7,03	8,04
22	34	2,76	3,27	3,98	4,09	7,05	8,17
26	38	2,92	3,46	4,21	4,32	7,56	8,64
18	26	2,95	3,50	4,26	4,37	7,65	8,74
22	30	3,13	3,70	4,51	4,63	8,10	9,26
26	34	3,26	3,86	4,71	4,83	8,45	9,66
14	18	3,31	3,93	4,79	4,91	8,59	9,82
30	38	3,36	3,99	4,86	4,98	8,72	9,97
18	22	3,49	4,13	5,04	5,17	9,04	10,33
22	26	3,61	4,27	5,21	5,34	9,35	10,68
26	30	3,69	4,38	5,33	5,47	9,58	10,94
30	34	3,76	4,46	5,43	5,57	9,75	11,14
34	38	3,81	4,52	5,51	5,65	9,89	11,30
22	22	4,26	5,05	6,16	6,31	11,05	12,63
38	34	4,76	5,64	6,88	7,06	12,35	14,11
34	30	4,83	5,72	6,98	7,16	12,52	14,31
30	26	4,92	5,83	7,10	7,28	12,75	14,57
26	22	5,04	5,97	7,27	7,46	13,06	14,92
22	18	5,21	6,17	7,52	7,72	13,50	15,43
38	30	5,40	6,40	7,80	8,00	13,99	15,99
18	14	5,48	6,49	7,91	8,12	14,21	16,23
34	26	5,57	6,60	8,05	8,26	14,45	16,51
30	22	5,81	6,89	8,39	8,61	15,07	17,22
26	18	6,16	7,30	8,89	9,12	15,96	18,24
38	26	6,23	7,38	9,00	9,23	16,15	18,45
34	22	6,59	7,81	9,51	9,76	17,07	19,51
22	14	6,70	7,94	9,67	9,92	17,36	19,84
30	18	7,10	8,42	10,26	10,52	18,41	21,04
38	22	7,36	8,72	10,63	10,90	19,08	21,81
26	14	7,91	9,38	11,43	11,72	20,52	23,45
34	18	8,05	9,54	11,63	11,93	20,87	23,85
38	18	9,00	10,66	12,99	13,33	23,32	26,66
30	14	9,13	10,82	13,19	13,53	23,68	27,06
34	14	10,35	12,27	14,95	15,33	26,83	30,66
38	14	11,57	13,71	16,71	17,14	29,99	34,27

Sistema PRECISION PLANTING - PNEU Ø 1072

* Metro Linear / Linear Meter / Metro Lineal

05.03.03.4682 - Revisão 00 - 0618

Adjustments and operations

Calculation of the amount of seeds

Calculation of seeds/meter according to the different number of holes in the seed plates.

When using a seed plate that has a number of holes that is not included in the table, it is possible to find the amount of seeds/meter it will distribute by doing the calculation below:

In the table from the previous pages, for a seed plate that has 24 holes (**mechanical**) or 27 holes (**pneumatic**) on a **26 x 38** combination, the amount of seeds/meter is **2.63** (**mechanical**) or **2.96** (**pneumatic**).

Use the table from the page 78 as an example.

Example:

Using the same transmission combination (**26 x 38**) but now using a seed plate with **20 holes**, follow the calculation below.

Formula:

Multiply the amount of seeds per meter (table = **2.63**) by the amount of holes (holes in the new plate = **20**) and divide by the amount of holes (seed plate on the table = **24**).

Calculation:

$$\frac{2.63 \times 20}{24} = \frac{54.6}{24} = \mathbf{2.19 \text{ seeds per linear meter.}}$$

Answer:

Using a seed plate with 20 holes, **2.19** seeds per linear meter will be distributed (**26 x 38** combination).

NOTE

Use the same method for every table to calculate the amount of seeds/meter, being it mechanical or pneumatic.



Adjustments and operations

Fertilizer distribution

The fertilizer distribution is made through the augers and the different rates are adjusted by the sprocket combinations of the Drive shaft {A} (14, 18, 22, 26, 30, 34 and 38 teeth) and Driven shaft {B} (14, 18, 22, 26, 30, 34 and 38 teeth).

Procedures to change the sprockets

- Move the lever to relieve the chain tightener and lock it using a pin.
- Manually displace the set of sprockets in the shaft and align the chosen sprocket with the chain.
- Release the lever to loose the lock pin.



NOTE

The cone bolts on the sprockets handling "TRA" are pre-adjusted on the factory, allowing to change the sprockets without using any tool.

In case of any sliding motion on the cone shaft, just release the counter nut and turn around the bolt to re-lock.

In order to avoid damage to the spring and shafts, never apply excessive torque when tightening.

IMPORTANT


See the different amounts of fertilizer distributed for several spacings, according to the sprocket combinations.

The seed and fertilizer distribution tables of this manual must be used as a reference to start the planter adjustment. Factors such as the slippage index of the planter wheels (skidding), working speed, tire inflation, field conditions, seed type and others can make the values differ from the ones in the table. Therefore, it is always indispensable to make the practical distribution tests, as indicated on page 86.

Adjustments and operations

ATTENTION

- The table {A} on the following page shows the obtained amount with the 2" coil pitch augers (standard). This auger transports approximately 35 grams of granulated commercial fertilizer per turn.
- The table {B} on the following page shows the obtained amount with the 1" coil pitch auger (optional). This auger transports approximately 17 grams of granulated commercial fertilizer per turn.



Safety fuse of the transmission

To protect the seed and fertilizer system, the planter has safety fuses on the drive shafts and hexagonal shafts. Whenever necessary, replace for an original one.

Adjustments and operations

IMPORTANT

The data on the previous tables (seed and fertilizer) can vary due to several factors. Therefore, carefully observe the following procedures.

Practical test of seed and fertilizer distribution

The most indicated way to assess the amount of seed and fertilizer rate is performing the test on the same field the plantation will take place, following these steps:

- Whenever possible, use the same tractor and operator to perform the plantation.
- The correct inflation of the planter tires is important to maintain uniformity in the plantation. Keep the same pressure on all tires.
- Mark the distance for the test. Fertilizer table example: 50 linear meters.
- Fill up the planter hoppers at least to the half and then travel some meters to completely fill the meterings before entering in the delimited area.
- Place the collection bags in the fertilizer dispensers (preferably use plastic bags). In the seed dispensers, use cotton waste to hinder the exits.
- Drive the tractor in the delimited space, using the same speed that will be used in the whole plantation.
- Recommended speeds:
 - 5 to 5.5 km/h for corn and sunflower plantation.
 - 6 to 6.5 km/h for bean/sorghum/acid delinted cotton plantation.
 - 7 km/h for soybean plantation.
- Maximum transport speed: 15 km/h.
- Weigh the fertilizer contained in the bags and compare it to the second line of the previous tables (grams in 50 meters per row unit).
- Remove the cotton waste of the seed dispensers, picking up the seeds for counting.
- Compare with the table and, if necessary, redo the tests changing the adjustments.
- After getting the desired amount and still in the field, move the tractor in the same speed, leaving the fertilizer and seed to reach the soil for better verifying the distribution uniformity.

ATTENTION

- The working speed affects the uniform seed distribution.
- When there is a change in the batch of seeds as well as in the fertilizer manufacturer, everything must be assessed again.
- It is important to assess all adjustments again after the first day of work.

Adjustments and operations

Auxiliary calculation for fertilizer distribution

To distribute other amounts of fertilizer in different spacings and areas from those presented in the tables we suggest a quick calculation, where all used data can be changed to one of your own interest. Use the formula below, which contains the following elements:

A = Area to be fertilized (m²).

B = Spacing between rows of the crop (m).

C = Amount of fertilizer to be distributed in the area (Kg).

D = Distance to travel for the distribution test (m).

X = How many grams should be dropped in "d"?

Formula:

$$X = \frac{B \times C \times D}{A}$$

Example:

A = 10,000 m²

$$X = \frac{0.90 \times 250 \times 50}{10,000}$$

B = 0.90 m

$$X = \frac{11,250}{10,000}$$

C = 250 kg

D = 50 m

$$X = 1.125 \text{ kg or}$$

X = ?

X = 1,125 grams in 50 meters in each row unit.

Adjust the equipment to distribute the found amount or the best approximation in the delimited space for the test.

Adjustments and operations

Oscillating disc blades (no-till)

The disc blades have lateral oscillation movements to follow the curves on the terrain.

The disc blade will be useful when cutting straw and not for opening furrows.


Adjust the spring (A) according to the situation of the terrain.

Do not perform sharp turns during working, as this act may cause damages to the row components.

The vertical oscillation (or flotation) of the disc blades is provided by the springs, which allows the necessary articulation to follow the soil profile and to transpose obstacles.

The disc blades support have a height adjustment and it should be used to increase or to decrease the depth cut of the disc blades related to the soil.

Avoid to deepen the disc blades unnecessarily.




ATTENTION Avoid that the disc flange touch the soil.

Adjust the spring pressure uniformly on every row unit.

Opening the seed furrows

The furrows for seeds are opened through unaligned double discs; which possess flexible and adjustable scrapers in order to remove earth that accumulate in their internal parts.



Adjustments and operations

Opening the seed furrows

The furrows for seeds are opened through unaligned double discs; which possess flexible and adjustable scrapers in order to remove earth that accumulate in their internal parts.

The seed rows feature adjustments to control the working pressure over the soil:

Holes in the upper bar of the parallelogram.

"1" - Greater pressure.


"2" - Smaller pressure.

Holes in the lower bar of the parallelogram.

"A" - Greater pressure.


"B" - Smaller pressure.

Set the same adjustment for every row unit.



Seed depth and floating range of the row unit

The seed depth control is made individually through the gauge wheels (A), which possess adjustments through the handler (B). The graduation allows to adjust the seed depth in intervals of **0.5 cm** or **1 cm**. (Check figure on the following page).





NOTE

The depth gauge wheels possess independent lateral and vertical oscillation to follow the differences of the ground undulation.

Adjustments and operations

Seed depth and floating range of the row unit





0.5 cm

1 cm


Press wheels adjustment

The press wheels in "V" shape firm the soil around the seed and are able to work in several positions according to the soil type and conditions of the straw.

- 1) Make the correct adjustment of the floating range and the downward pressure by the lever (A) that allows to operate in four positions and one neutral position.
- 2) Adjust the angle between the tires (vertex) through the lever (B) that allows more or less pressure on the wheel.



With the wheel angle closed, there will be less earth over the seed.



With the wheel angle opened, there will be more earth over the seed.

NOTE


While adjusting the press wheels it is important to consider the soil type, seed type and depth of planting to not affect the plants emergence.

Adjustments and operations

Electromagnetic clutch

With automatic activation for maneuvers and finishings.

When the clutch (A) is activated, the TRA transmission axle stops turning.



Adjustments and operations

Row markers

The row marker utilization is very important to achieve an uniform spacing in the plantation, thus facilitating the cultivation and harvest.

NOTE For this practical adjustment it is necessary to keep the front and rear gauges with the same measure, being the central measure of the front tires equal to the rear ones.

Follow the instructions that goes along with the illustration on the next page.

To adjust the marker discs it is just necessary to loosen the nuts and dispace the extensor to the desired position. This distance can be obtained as follows:

- Drive some meters on a prepared soil, being the planter hitched.
- Measure the distance (A) between the center of the tractor trace and the center of the first seed row (row in the planter extremity).
- Sum up the found measure with the spacing between rows (B) measure, considering the spacing that is being used in the equipment.
- The result is the distance (C) that should exist between the row marker disc and the center of the first seed row (row in the planter extremity).

Example:

A - Tractor trace center to the center of the first seed row = 800 mm.

B - Spacing between row crops = 500 mm.

C - Distance to be found (?).



So: A + B = C

$$800 + 500 = 1,300 \text{ mm}$$

$$C = 1,300 \text{ mm}$$

This is the distance between the center of the first seed row and the marker disc lowered to the soil.

Adjustments and operations




Working angle

The marker discs feature angle and distance adjustments to facilitate the soil opening. In order to do so, loosen the nut and adjust as necessary.


Adjustments and operations

Working angle related to the soil

Equipments composed by lateral articulated frames with angles that change from 1° to 7° degrees to make it easier to work on different types of soil.



USAP SUPREMA



USAP SUPREMA CSH

Adjustments and operations

Operations - Important points



- Retighten nuts and bolts after the first day of planting. Check the conditions of all pins and cotter pins. Then, retighten every 24 working hours.
- Carefully observe the lubrication intervals.
- The correct inflation of the tires is important to maintain the planting uniformity. Keep the same inflation for all tires.
- When filling up the planter, observe its proper hitching to the tractor. Verify if there is any object inside the hoppers that may cause damage to the metering devices.
- Always use seeds and fertilizer free from impurities.
- Inspect the seed metering systems twice a day and remove the adherence of chemical products from them, if necessary.
- Keep the equipment leveled.
- Periodically check the established adjustments in the beginning of the plantation.
- Carefully check the seed depth and the compaction pressure.
- It is important to maintain a constant speed in the whole plantation.
- The tractor drawbar must remain fixed.
- Use the row markers correctly to avoid future wastes.
- Never make maneuvers or use reverse gear when the rows are touching the soil.
- Never make sharp turns during the service, especially in a no-till plantation. The row components may be damaged.
- To make any verification in the equipment, it is necessary to lower it to the ground and shut down the tractor engine.
- For adjustment and verification of the cutting parts (row units) of the equipment, it is necessary to disconnect the clutches to avoid wastes.
- During working or transportation, the presence of passengers on the tractor or equipment is not allowed.
- As previously mentioned, the planter features several adjustments. However, only the local conditions can determine the best adjustment thereof.

Maintenance

Lubrication

In order to reduce the wearing caused by the friction in the moving parts of the equipment, it is necessary to make a correct lubrication, as indicated below.


- Every 24 working hours, lubricate the articulations through the grease fittings according to the following instructions:
 - Be certified about the lubricant quality, with relation to its efficiency and purity, avoiding the use of products contaminated by water, earth and others.
 - Remove the remainder old grease around the articulations.
 - Clean up all the grease fittings with a cloth before introducing the lubricant and replace the defective ones.
 - Introduce an enough amount of new grease.
 - Use medium consistency grease.

ATTENTION

Special attention should be given to the lubricant intervals on the different points of the planter.

Maintenance

Lubrication points



ATTENTION Lubricate the points shown above and all grease fittings as well.

Maintenance

Lubrication points




ATTENTION Lubricate the points shown above and all grease fittings as well.

Maintenance

Fertilizer metering maintenance

For the correct fertilizer maintenance or to make any kind of repair in its internal parts, proceed as follows:

- Remove the squared shaft (A) with bevel gear (B) and the bearing (C).
- Remove the inner squared shaft (D), along with the bevel gear (E), bearing (F) and the fixation nut (G) by the frontal part of the metering.
- Remove the grease fitting (H) from the rear part of the metering to release the other parts as shown in the illustration and replace the defective ones.
- Assemble the metering system again observing the correct position of the right and left augers.
- Do not forget to lubricate the metering grease fittings daily, as mentioned on the 'lubrication' page, avoiding future problems.




NOTE To improve the fertilizer dropping, use the fertilizer tube (I).

Maintenance

Cleaning the seed metering

It is necessary to make a general cleaning in each seed metering daily. To do this, remove the seed plate and observe the metering mechanism operation. By doing so, the best planting will be assured.




NOTE

When using graphite powder with treated/inoculated seeds, it is necessary to clean the system twice a day.




Maintenance of the row hubs

- When the existence of looseness is noticed, it is necessary to make the maintenance in the hubs of the disc blades, unaligned double discs, gauge wheels and press wheels.
- Disassemble the hubs and remove the internal components.
- Clean all parts with diesel oil and kerosene.
- Verify the existence of looseness and the conditions of the bearings, retainers and bushings. Replace the damaged components or with excessive torque.
- The hubs without grease fittings should be reassembled with a good amount of lubricant.
- The hubs with grease fittings should be lubricated until the new grease is visible.
- The hubs with tapered roller bearings fastened by castle nut and cotter pin allow the adjustment of the inner clearance; excessive tightening should be avoided. The hubs should rotate with the hand applying a small effort.



Maintenance

How to replace the tires



When the planter tires need repairs, proceed as follow:


Totally lift the planter and place the locks (A) on the cylinders, but leave the tire that is going to be replaced without a lock.

Totally retreat the hydraulic cylinder to lift the tire from the soil.

When it is a tire with transmission that is going to be replaced, remove the cover (B) by loosening the bolts (C), flat washers, spring washers and butterfly nuts. Then, release the tire (D) by loosening the guide bushing, flat washer, castle nut (E) and cotter pin.



Check if the planter is properly supported to avoid accidents.






Optional

Seed plates

Optionally, MARCHESAN supplies slotted or perforated seed plates for several crops, according to the list below:

Seed plates	Amount of holes/slots	Hole/slot dimension	Thickness	Serial number
Corn (Black)	28 slots	15.5 x 11.5 mm	4 mm	05.03.01.6194
Corn (Red)	28 slots	14.5 x 10 mm	4 mm	05.03.01.6195
Corn (Green)	28 slots	13.5 x 9 mm	4 mm	05.03.01.6196
Corn (Salmon)	28 slots	12.5 x 8.5 mm	4 mm	05.03.01.6197
Corn (Gray)	28 slots	12.3 x 9.4 mm	4 mm	05.03.01.6198
Corn (White)	28 slots	11.5 x 8.5 mm	4 mm	05.03.01.6199
Corn (Pumpkin)	28 slots	11 x 8 mm	4 mm	05.03.01.6200
Corn (Gray)	28 holes	13.5 mm	4 mm	05.03.01.6201
Corn (Pink)	28 holes	13 mm	4 mm	05.03.01.6202
Corn (Light blue)	28 holes	12.5 mm	4 mm	05.03.01.6203
Corn (Light green)	28 holes	11.5 mm	4 mm	05.03.01.6205
Corn (Blue)	28 holes	10.5 mm	4 mm	05.03.01.6207
Corn (Yellow)	28 holes	10 mm	4 mm	05.03.01.6208
Corn (Gray)	28 holes	9.5 mm	4 mm	05.03.01.6209
Corn (Dark green)	28 holes	9 mm	4 mm	05.03.01.6210
Corn (Purple)	28 holes	8 mm	4 mm	05.03.01.6211
Corn (Red)	28 holes	14 mm	4 mm	05.03.01.6212
Corn (Black)	28 holes	15 mm	4 mm	05.03.01.6213
Ring for corn with recess of 1 mm (Green)	—	—	1 mm	05.03.01.6215
Ring for corn with recess of 2 mm	—	—	2 mm	05.03.01.6216




Optional

Depth control system with gauge wheel

Assemble the laced wheels (A) to the depth control (B) using bolts (C), spring washers and nuts.

Assemble the "V" gauge wheels (D) to the depth control (B) locking it using bolts (E), bearing cover, retention ring and adjustable shim.

Then, lock it to the seed unaligned double disc.



Optional

TATU precision agriculture (APT)

The APT system was created with an electronic communication pattern that allows that products from different manufacturers communicate with one another. Thus, it is possible to control all equipments from a single terminal station.

The system will be operated from the tractor cab by a virtual terminal (VT) that can command every function.

Benefits:

- ISOBUS standard quick coupler connector for proper fitting and quick installation;
- ISOBUS communication, which allows a quick adaption of tractor and equipments;
- Fullscreen alarms;
- Hydraulic control valves (PWM);
- Several monitoring and control systems in a single screen. More room in the cab and reduction in the amount of wires;
- Monitors up to 200 row units;
- Compatible with level monitoring, pressure and rotation sensors;
- Keeps the information, even when there is a lack of energy;
- Flat and floating rate application;
- Input reduction, productivity and profitability increasement.

Costs reduction:


- All the mechanical transmission system (clutches, clutches shafts, chain and wheelset tighteners, sprocket combinations, manual operations, seed and fertilizer tables) will be eliminated;
- Wheelset skidding that activates the transmission shafts;
- Field tests and the subsequent adjustment fixes;
- Every planter model can receive the hydraulic/electronic system to replace the mechanical transmission.

Easy maintenance:


- The color pattern of the cables and the diagnosis center in a single terminal station facilitates the discovery of possible problems.

Optional

TATU precision agriculture - Components connection



Titanium Apollo




Assembly

Seed dosing system for mechanical machines

- Titanium is a mechanical distribution seed system. It provides an easy maintenance to the farmer.
- It is an easy-to-use equipment because it works as a seed plate. It features several technologies in order to provide a greater security and an excellent planting to the farmer.

Components and assembly



Set-up instructions

Standard seed plates - TITANIUM

Seed plates	Amount of holes	Serial number
CORN	28 holes	05.03.01.6204
SOYBEAN	90 holes	05.03.01.6217
SOYBEAN	90 holes	05.03.01.6218


Optional seed plates - TITANIUM

MARCHESAN optionally supplied seed plates for several cultivations, according to the list below:

Seed plates	Amount of holes	Serial number
CORN	27 holes	05.03.01.8481
CORN	27 holes	05.03.01.8482
BEAN (MEDIUM)	70 holes	05.03.01.8468
SOYBEAN	80 holes	05.03.01.8483
BEET / ONION	32 holes	05.03.01.8496
SORGHUM	32 holes	05.03.01.8159
PEANUT	32 holes	05.03.01.8497
CANOLA	80 holes	05.03.01.8498



Maintenance

Main technologies



View: Allows a real time visualization of the seed plate while working, what is practical when choosing the plate and to adjust it when planting incorrectly (skip/double seeds).

Flex brush: Remove the seeds that did not fall by gravity. Its contact with the seeds provide less friction and less damage to them. It is possible to plant 05 (five) cultures without changing it, just being necessary to change the seed plate and rings.



Brush flow (Organizers): There are four organizers inside the box, designed in polyurethane. This system drastically reduces the possibility of mechanical damages (breaks, cracks and others) in the seeds and also raise the chances of the seeds to remain organized in the seed plate holes.

Maintenance

Graphite powder use



It is very important to use graphite on TITANIUM. The average use of graphite per seed hopper is 200 - 240 grams, depending on the seed type or the treatment that was applied on them.

The graphite must be mixed to the seeds uniformly during plantation and always on the dry seeds.

Never mix graphite with the liquid treatment, because it takes away the lubricant capacity of the graphite, so the seeds will turn to black but will not be lubricated.

Graphite (powder) is the last treatment that should be applied to the seeds and has the purpose to lubricate them to eliminate doubles, skipping, wearing on the rings, seed breaking and premature wear on Brush flow and Flex brush components.

Some farmers know the benefits of using graphite for a perfect distribution and usually mix the graphite to the seeds by putting half of a seed bag on a plastic bag (fertilizer bag, for example) and shaking to assure that all seeds will be equally lubricated.





Precision Planting vacuum seed meter / Precision Planting with Vdrive

Assembly

Turbine with hydraulic motor

- Fasten the hoses (A) to the hydraulic motor (B). Observe if the terminals are clean and avoid that they touch the soil.
- Couple the male quick couplers (C) to the hoses, with proper tightening to avoid leaks.

NOTE Use thread sealing tape to couple the hoses to the male quick couplers.



Hydraulic activation

Tractors with hydraulic system. Priority control valve with variable flow.

This valve has the hydraulic system and tractor priority and works when the equipment is lifted or when the tractor steering wheel is used and avoids a slower rotation in the turbine.

A - Priority valve with variable flow.

B - Turbine with hydraulic motor.

C - Free return to the reservoir, which should not have pressure in order to not damage the motor.

NOTE

For tractors which not have a direct free return (C) to the reservoir, it is necessary to consult your dealer to make the adaption.

Set-up instructions

PRECISION PLANTING seed plates

MARCHESAN optionally supplies seed plates for several cultures, according to the table below:

Use a good amount of graphite
Color on table corresponds to actual color of parts
BOLD components are included in the kit

* WaveVision identify seeds starting from 3mm

** Milo screens needed for Central fill planters only

***For optimal performance with large long seeds, the singulator may need to be removed

****For some seed sizes it may be necessary to remove the baffle completely to prevent bridging of large seeds

Crop	Field Corn	Soybean	Sweet Corn			Popcorn		
			Small	Medium	Large	X-Large	Small	Medium
Size (Qualitative)								
Size (Seeds/KG)	2200-6200	4400-10000						
Vacuum (Inch of water)	20"	20"	18"-22"	18"-22"	18"-22"	18"-22"	20"	20"
Vacuum (millibar)	50	50	45 - 50	45 - 50	45 - 50	45 - 50	60	60
Vacuum (PSI)	0.722	0.722	0.65-0.72	0.65-0.72	0.65-0.72	0.65-0.72	0.72	0.72
Baffle position	2	2	4	4	4	4	2	2
Kit Part #	05.03.06.2417	05.03.06.2407						
Seed plate	Name	Corn	Soybean	Specialty	Specialty	Specialty	Specialty	Specialty
# of holes	27	80	27	27	27	27	27	27
Rows on field	single	double	single	single	single	single	single	single
Hole size (inches)	0.176	0.155	0.125	0.135	0.145	0.155	0.115	0.125
Hole size (mm)	4.470	3.937	3.175	3.429	3.683	3.937	2.921	3.175
PN	05.03.01.8481	05.03.01.8483	05.03.01.8491	05.03.01.8492	05.03.01.8493	05.03.01.8494	05.03.01.8482	05.03.01.8491
Singulator	Name	Corn	Soybean	Corn	Corn	Corn	Corn	Corn
PN	05.03.06.2472	05.03.06.2569	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472
Ejector	Name	Corn	Soybean	Specialty	Specialty	Specialty	Specialty	Specialty
PN	05.03.06.2474	05.03.06.2566	05.03.06.2570	05.03.06.2570	05.03.06.2570	05.03.06.2570	05.03.06.2570	05.03.06.2570
Additional Components	Description							
PN								
WaveVision recommended for Population monitoring?	Yes	Yes						

Set-up instructions

PRECISION PLANTING seed plates

Use a good amount of graphite
Color on the table corresponds to actual color of parts
BOLD components are included in the kit

* WaveVision identify seeds starting from 3mm

** Milo screens needed for Central fill planters only

***For optimal performance with large, long seeds, the singulator may need to be removed

****For some seed sizes it may be necessary to remove the baffle completely to prevent bridging of large seeds

Crop	Sorghum / Milo	Pumpkins	Cotton	Edible Beans		
Size (Qualitative)				Small	Medium	Large
Size (Seeds/KG)	26K-42K	-	9300-14000	> 4400	2860-4400	< 2860
Vacuum (Inch of water)	10"-16"	11"-12"	20"	18"-22"	18"-24"	18"-26"
Vacuum (millibar)	25 - 40	27 - 30	60	45 - 55	45 - 60	45 - 65
Vacuum (PSI)	0.36 - 0.58	0.4 - 0.43	0.72	0.65-0.8	0.65-0.87	0.65-0.94
Baffle position	1	3	2	2	3	4
Kit Part #	05.03.06.2471		05.03.06.2586	05.03.06.2407	05.03.06.2564	05.03.06.2573
Seed plate	Name	Large sugar beet	Specialty Cotton	Soybean	Medium Edible Bean	Large Edible Bean
# of holes	32	27	32	80	70	32
Rows on field	single	single	single	double	double	single
Hole size (inches)	0.086	0.125	0.115	0.155	0.17	0.21
Hole size (mm)	2.184	3.175	2.921	3.937	4.318	5.334
PN	05.03.01.8159	05.03.01.8491	05.03.01.8529	05.03.01.8483	05.03.1.8468	05.03.01.8495
Singulator	Name	Corn	Corn	Soybean	Bean	Soybean
	PN	05.03.06.2472	05.03.06.2472	05.03.06.2569	05.03.06.2565	05.03.06.2569
Ejector	Name	Sugar beet	Specialty	Soybean	Soybean	Large Edible Bean
	PN	05.03.06.2473	05.03.06.2570	05.03.06.2473	05.03.06.2566	05.03.06.2571
Additional Components	Description	Milo screen**		L Seed Upper Brush	L Seed Upper Brush	
	PN	05.03.01.8499**		05.03.01.8469	05.03.01.8469	05.03.01.8469
WaveVision Recommended for Population monitoring?	Yes*			Yes	Yes	Yes

Set-up instructions

PRECISION PLANTING seed plates

Use a good amount of graphite

Color on table corresponds to actual color of parts

BOLD components are included in the kit

* WaveVision identify seeds starting from 3mm

** Milo screens needed for Central fill planters only

***For optimal performance with large, long seeds, the singulator may need to be removed

****For some seed sizes it may be necessary to remove the baffle completely to prevent bridging of large seeds

Crop		Sunflower				Canola		Peanut
Size (Qualitative)	Large Edible	Small Edible	#1	#2	#3	#4		
Size (Seeds/KG)	4400-8800		6,6K - 10K				166K-400K	445-3111
Vacuum (inch of water)	12"-13"	11"-12"	11"-12"	11"-12"	7"-8"	6"-7"	22"-26"	20"-30"
Vacuum (millibar)	30 - 32	27 - 30	27 - 30	27 - 30	27 - 30	15 - 17	55 - 65	50 - 70
Vacuum (PSI)	0.43-0.47	0.4 - 0.43	0.4 - 0.43	0.4 - 0.43	0.25 - 0.29	0.21-0.25	0.8 - 0.94	0.70 - 1.08
Baffle position	4	4	4	4	3	2	4	4****
Kit Part #	05.03.06.2417	05.03.06.2417	Corn	Specialty	Specialty	Specialty	05.03.06.2575	05.03.06.2576
Seed plate	Name	Corn	Corn	Specialty	Specialty	Specialty	Canola	Peanut
# of holes	27	27	27	27	27	27	80	32
Rows on field	single	single	single	single	single	single	double	single
Hole size (inches)	0.176	0.176	0.155	0.135	0.115	0.115	0.047	0.23
Hole size (mm)	4.470	4.470	3.937	3.429	2.921	2.921	1.193	5.842
PN	05.03.01.8481	05.03.01.8481	05.03.01.8494	05.03.01.8492	05.03.01.8482	05.03.01.8489	05.03.01.8497	
Singulator	Name	Corn	Corn	Corn	Corn	Corn	Corn	Soybean **
PN	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2472	05.03.06.2569
Ejector	Name	Corn	Corn	Specialty	Specialty	Specialty	N/A	Large Edible Bean
PN	05.03.06.2474	05.03.06.2474	05.03.06.2570	05.03.06.2570	05.03.06.2570	05.03.06.2570	N/A	05.03.06.2571
Additional Components	Description	L Seed Upper Brush					Wiper Kit	L Seed Upper Brush
WaveVision Recommended for Population monitoring?	PN	05.03.01.8469					05.03.06.2572	05.03.01.8469
							No Pop. Mon.	

Adjustments and operations


Changing the metering set

The metering set is composed by a seed plate, selector and ejector.

To change or fix the metering set, proceed as follows:

Place the ejector set (A) in the carcass; then place the seed plate (B) and lock using the pin (C). Lastly, place the selector (D).

To remove the parts, do the reverse operation.




NOTE Special attention should be given when placing the seed plate. Be sure to not curl or smash the seal. If there is any damage such as cracks or mends in the seal, replace it immediately.

Adjustments and operations

Baffle position

Precision planting has an adjustment to input the seeds situated in the metering with 4 (four) adjustment levels, which the operator can adjust according to the seed size.

For a better performance in the plantation, the operator should follow the tables from the previous pages.



vDrive components maintenance

- When finishing and restarting the planting season, clean the harness connection that were exposed to the environment.
- When using a pressure washer, do not direct water jet to the electronic modules (SRM, Power Module, PDM, Smart Connector, RUM, vDrive etc), seed meterings and harness connections.
- When disconnecting a connection during the planting season for maintenance or disassemble purposes, the exposed connectors must be protected from the environment.

NOTE

- WaveVision identify seeds starting from 3 mm.
- Milo screens needed for Central fill planters only.
- For optimal performance with large, long seeds, the singulator may need to be removed.
- For some seed sizes it may be necessary to remove the baffle completely to prevent bridging of large seeds.
- In some planting situations the owner should only replace the singulator, ejector or seed plate.

Adjustments and operations

Appropriate suction

The appropriate suction is obtained after driving some meters with the planter, when the seeds are already housed in all the holes of the plate.

Maintain the command lever constantly activated in a way that it keeps sending oil without interruptions during the whole plantation.

The proper adjustment of the flow control valve depends on the amount of row units of the planter and type of seeds.

Vacuum meter suction verification

The values between 40 and 90 millibars of vacuum are adequate for most light, medium and heavy seeds.

NOTE Whenever adjusting the valve, it is necessary to make a verification in the seed plate performance.



Attention: Safety hazard or damages to the equipment

- PTO rotation should be kept in 540 rpm during the whole job.
- Consult the tractor manual and adjust the PTO rotation speed to 540 rpm before turning it on.
- If the rotation speed is not properly adjusted or is over 540 rpm, damages to the equipment or critical accident may occur.
- Marchesan is not responsible for the inadequate use of its equipment.

Adjustments and operations

Vacuum meter installation

The ambient temperature must not exceed 140°F (60°C). Also, avoid direct sunlight which accelerates discoloration of the clear plastic cover.


All vacuum meters are calibrated with the diaphragm vertical and should be used in that position for maximum accuracy.

Vacuum meter assembly

Couple the hose (A) from the turbine to the negative pressure spigot (B) on the rear part.

Place the filter (C) on the positive output ("+") and always let the hole facing down.

Couple the breather (D) to the filter in order to protect the inner part of the meter.




Set-up instructions

Due to the atmospheric pressure and the ambient temperature, the bolt (E) is used to adjust the vacuum meter to zero.

How to set the vacuum meter to zero:


- Turn off the turbine and wait for the blower to stop;
- Put a screwdriver on the bolt below "ZERO SET" to adjust the vacuum meter;
- Set it to zero with gentle movements;
- The indicator will move farther from zero on a clockwise movement and closer to zero on a counterclockwise movement;
- Never use sharp objects to adjust, such as a switchblade. They may damage the seal.



Adjustments and operations

Vacuum meter recommendations

- It is not necessary to lubricate the vacuum meter;
- Always keep the outer protection and the plastic cover cleaned;
- To equalize the inner and outer pressure it is necessary to use the filter on the rear part of the meter and keep it facing down, so water will not enter inside the equipment;
- When the vacuum meter stops working, the first procedure is to clean the filter;
- Never operate without the filter;
- When washing the equipment, protect the inner part from the water (if there is water inside the equipment, the warranty will void);
- There is a device that works as a relief valve (F) on the rear part of the meter. This device opens at approximately 25 psig. It is necessary to close it again to protect the inner part of the equipment.



Troubleshooting tips

Vacuum meter not indicate or is sluggish:

- Pressure port is without the relieve valve;
- Diaphragm ruptured due to overpressure;
- Fittings or sensing lines blocked, pinched, or leaking;
- Cover loose or "O" ring (G) damaged, missing;
- Do not loose or remove the lateral plugs (H);
- Pressure sensor improperly located;
- Never clean the filter using tools. Remove it, wash with water and dry using compressed air.


ATTENTION

Never let water enter inside the vacuum meter, this act may damage your equipment and void your warranty.

Adjustments and operations

Stopping the seed flow

To change the seed plates or for any internal inspection in the metering, use the interrupters (A) and release the butterfly nut to isolate the amount of seeds in the hoppers.




NOTE After the inspection, tight the butterfly nut properly so it will not get loose during operation.

Maintenance

Pneumatic sealing

The pneumatic sealing (A) is a device that assures the vacuum directioning, where the suction only acts in the seed hoppers with no vacuum in the area of release. The seeds are released in the center of the conductor.



Seed metering maintenance - Precision Planting

During the planting recess, disassemble every seed metering and check the following points:

- Wearing of the seed selectors (B) and ejector (C).
- Pneumatic sealing (A) - check if there is no crack or wearing.
- Seed plates (D) - replace them if the holes get deformed or if the seeds are going to the vacuum side.


Then, use compressed air to clean every metering system.

In disuse period disassemble every metering system, remove all components of the metering set and store in a clean place.

NOTE

- Spray powder graphite in the pneumatic sealing (A).
- Never use sharp turns or metallic objects to scrape the seed plates.

Central seed hopper



USAP Suprema with central seed hopper

Assembly

Air duct assembly on the central seed hopper


The USAP SUPREMA planter has a version with a central seed hopper that is pre-assembled on the frame.

For a better performance on the plantation, the hoppers were distributed on the frames to assure a proper weight distribution.

This seed hopper also has a suction/pressure system, which allows the suction or pressurization of the row units with the aid of the turbines (A).

The air hoses (B) on the seed hopper and air hoses (C) of the seed meterings are coupled to the air ducts using clamps (D) after joining the lateral frames.

The other hoses (where the seeds go through and the air distribution ones) are pre-assembled on the factory.




Maintenance

Cleaning the central seed hopper

After using the equipment it is necessary to clean the central seed hoppers (A) by releasing the quick locking (B) and opening the bottom covers (C), thus having a free space to clean the hopper.

The cover (D) is used to couple the vacuum meter of the central seed hopper (A) and also to clean the hopper where it must be removed every two or three days for cleaning up.



NOTE The cover (D) can be coupled to a vacuum meter for the verification of air entering inside the hopper (A).

The ideal working pressure must be between 20 to 60 millibars, depending on the type of seed to be planted.

Maintenance

Planter maintenance

- Wash the whole planter using only water.
- Verify all moving parts of the planter for wearing occurrence. If necessary, replace some parts and leave the planter ready for the next planting season.
- Repair the damaged paintwork.
- Spray the metallic parts with protective oil. Never spray used engine lubricant oil.
- The driving mechanism chains should be removed at the end of the planting season, cleaned and stored in a recipient with oil until the next planting season.
- Clean and lubricate all grease fittings.
- Replace the missing or damaged safety stickers. Marchesan provide these stickers upon request and indication of the respective serial number. The operator must know the need to keep these stickers in place and in good conditions. Also, the operator must be aware that an accident can occur if the instructions are not followed.
- After making all repairs and maintenance cares, store the planter in a covered and dry place.
- Keep the planter properly supported and avoid the direct contact of the disc blades and tires with the soil.
- After finishing a job, clean up the seed hoppers by removing all the seeds and washing right after.
- Remove the hoses and air ducts, clean them and position them on the same place from where they were removed.
- Check if the battery used on the planter is in good conditions.
- Watch carefully the installation and handling position of the planter cables, since more than half of the maintenance causes are related to that.
- Regularly check the electric connections over the hydraulic control valve of the planter and also check the equipment - planter connector.

Maintenance

Troubleshooting

PROBLEM	CAUSES	POSSIBLE SOLUTIONS
Seed failures	- Low suction.	- Ideal PTO rotation speed; - Check the air hoses.
	- Improper selectors adjustment.	- Adjust the selectors properly.
	- Very small diameter of the seed plate holes.	- Use a seed plate with suitable holes to the seeds.
	- Excessive working speed.	- Ideal working speed: 5 to 7 km/h.
	- Odd material.	- Use seeds with pre-cleaning at least.
	- Lack of seeds in the metering.	- Check the deflector plate opening; - Interrupters are closed or semi-closed.
	- Worn-out selectors.	- Replace the selectors.
Duplicate seeds	- Dirty selectors.	- Clean with water, detergent and steel wool.
	- Obstructed holes.	- Clean with compressed air.
	- Improper selectors adjustment.	- Adjust the selectors properly.
Seeds over the ground	- Very big diameter of the seed plate holes.	- Use a seed plate with suitable holes to the seeds.
	- High seed level in the metering.	- Adjust the deflector plate.
Seeds over the ground	- Seed excess in the metering/ too high level.	- Check the opening of the deflector plate/ adequate to the seed size.
Irregular plantation	- Totally disadjusted seed plate.	- Adjust the hole diameter according to the seed.
	- Disadjusted selectors.	- Adjust the selectors properly.
	- Low suction.	- Check the PTO rotation speed; - Check the oil flow rate; - Check the hoses.
	- Worn-out tires.	- Replace for original ones.
	- Tires with different inflation.	- Inflate properly.
	- Tires with different design.	- Use tires with the same design.
	- Seed density not observed.	- Check the drive and driven shaft on both sides.
	- Skidding excess.	- Ballast the tires with water and apply pressure in the wheelset springs.
Damaged seeds	- Very big seed plate holes.	- Use a seed plate with an appropriate hole in accordance to the seed.
	- Worn-out rubber switch.	- Replace it.
Interruptions in the fertilizer metering	- Odd material in the fertilizer or cobbled fertilizer.	- Check the fertilizer quality.
	- Deformed fertilizer tube.	- Replace the tube.

Maintenance

Troubleshooting

PROBLEM	CAUSES	POSSIBLE SOLUTIONS
Metering for the seed	• Row unit without seed.	• Check the clutch; • Verify the vacuum.
	• Damaged safety pin.	• Replace it.
	• Obstruction by seeds.	• Set the deflector to a higher position.
	• Seed milling.	• Check the seed plate chock.
	• Very small hole diameter.	• Use a seed plate with appropriate holes related to the seeds size.
	• Obstructed holes.	• Clean them using compressed air.
	• Locked metering.	• Check the distributor to find the locking cause.
	• Excessive working speed.	• Ideal speed: 5 to 7 Km/h.
Too many skips	• Fragments on the distributor.	• Be sure that there is no fragments on the seed plate holes.
	• Failure on the singulator.	• Check if it is installed properly and if the rebounds are leveled against the seed plate surface.
	• Debris on the distributor.	• Check the outlet chute and the outlet of the seed tube.
	• Lack of pressure on the vacuum meter.	• Check if there is any leaking on the vacuum system.
Bad spacing	• Seeds deviation.	• Check the metering outlet chute and the outlet of the seed tube.
	• Distributors activation failure.	• Check the system to confirm if the chains are in good conditions and well lubricated.
	• Metering with noises.	• Remove the disc blade and look for debris that may be causing the noises.
	• Seed fragments between the seed plate teeth.	• Clean up and add chocks.
	• Seed in contact with the seed tube and with the outlet chute.	• Be sure that the seed reservoir is positioned in a way that the metering release the seeds on the center of the seed tube.
	• Lack of graphite.	• Be sure that the graphite is being used and being mixed to the seed hoppers.
Wrong population	• Hydraulic motors.	• Check the calibration and settings of the motor twice. • Check if the seeds per distributor rotation setting is correct.

Maintenance

Tires inflation

The tires must always be properly inflated, so there will not be a premature wear for excess/lack of pressure and thus assuring precision on the distribution.

TIRE - 12 X 16.50 / 12 tarps TR SK 900 (**65 PSI**).

TIRE - 14 X 17.5/14 TR SK 900 (**55 PSI**).

TIRE - 385/65 R 22.50 D 711 DRC 15-19.50 20 tarps (**130 PSI**).




Maintenance precautions



Caution! Hydraulic oil leakage may be strong enough to penetrate the skin and cause serious injuries to health. Oil leakage through a tiny hole may seem invisible. Use a piece of cardboard or wood instead of your hand to check a possible leakage.

Keep unprotected parts of the body, such as your face, eyes and arms as far as possible from a suspected leak. A splash of hydraulic oil can even cause gangrene or other maladies.

In case of such kind of accidents or any other, consult a doctor immediately. If such doctor does not possess proper knowledge of this kind of problem, ask for a referral or search to find the proper treatment.



NOTE Use TATU original parts only.

Maintenance

Torque table

Bolt Diameter	Grade 2		Grade 5		Grade 8	
	Coarse	Fine	Coarse	Fine	Coarse	Fine
1/4"	50 In. Lbs.	56 In. Lbs.	76 In. Lbs.	87 In. Lbs.	9 Ft. Lbs.	10 Ft. Lbs.
5/16"	8 Ft. Lbs.	9 Ft. Lbs.	13 Ft. Lbs.	14 Ft. Lbs.	18 Ft. Lbs.	20 Ft. Lbs.
3/8"	15 Ft. Lbs.	17 Ft. Lbs.	23 Ft. Lbs.	26 Ft. Lbs.	33 Ft. Lbs.	37 Ft. Lbs.
7/16"	25 Ft. Lbs.	27 Ft. Lbs.	37 Ft. Lbs.	41 Ft. Lbs.	52 Ft. Lbs.	58 Ft. Lbs.
1/2"	35 Ft. Lbs.	40 Ft. Lbs.	57 Ft. Lbs.	64 Ft. Lbs.	80 Ft. Lbs.	90 Ft. Lbs.
9/16"	50 Ft. Lbs.	60 Ft. Lbs.	80 Ft. Lbs.	90 Ft. Lbs.	115 Ft. Lbs.	130 Ft. Lbs.
5/8"	70 Ft. Lbs.	80 Ft. Lbs.	110 Ft. Lbs.	125 Ft. Lbs.	160 Ft. Lbs.	180 Ft. Lbs.
3/4"	130 Ft. Lbs.	145 Ft. Lbs.	200 Ft. Lbs.	220 Ft. Lbs.	280 Ft. Lbs.	315 Ft. Lbs.
7/8"	125 Ft. Lbs.	140 Ft. Lbs.	320 Ft. Lbs.	350 Ft. Lbs.	450 Ft. Lbs.	500 Ft. Lbs.
1"	190 Ft. Lbs.	205 Ft. Lbs.	480 Ft. Lbs.	530 Ft. Lbs.	675 Ft. Lbs.	750 Ft. Lbs.
1.1/8"	265 Ft. Lbs.	300 Ft. Lbs.	600 Ft. Lbs.	670 Ft. Lbs.	960 Ft. Lbs.	1075 Ft. Lbs.
1.1/4"	375 Ft. Lbs.	415 Ft. Lbs.	840 Ft. Lbs.	930 Ft. Lbs.	1360 Ft. Lbs.	1500 Ft. Lbs.
1.3/8"	490 Ft. Lbs.	560 Ft. Lbs.	1100 Ft. Lbs.	1250 Ft. Lbs.	1780 Ft. Lbs.	2030 Ft. Lbs.
1.1/2"	650 Ft. Lbs.	730 Ft. Lbs.	1450 Ft. Lbs.	1650 Ft. Lbs.	2307 Ft. Lbs.	2670 Ft. Lbs.



GRADE 2
No Marks.



GRADE 3
3 Marks.



GRADE 8
6 Marks.

NOTE

For metric conversion:

- Multiply inch-pounds by .113 to convert to newton-meters (Nm).
- Multiply foot-pounds 1.356 to convert to newton-meters (Nm).

Important

ATTENTION

MARCHESAN S/A reserves the right at any time to make improvements in the design, material or specifications of machinery, equipment or parts without thereby becoming liable to make similar changes in machinery, equipment or parts previously sold.

Images are for illustration purposes only.

Some illustrations in this manual appear without the safety devices, removed to allow a better view and detailed instructions. Never operate the equipment without these safety devices.

TECHNICAL PUBLICATION DIVISION

Elaboration / Diagramming: Valson Hernani de Souza

Diagramming Assistant: Ingrid Maiara G. de Siqueira

Illustrations: Reinaldo Tito Júnior

Technical information: Norair R. Furlanetto

Translation: Matheus Freire de Souza

October, 2018

Serial number.: 05.01.09.1869

Revision: 04



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS "TATU" S.A.

Marchesan Av., 1979 - P.O. Box 131 - Zip Code 15994-900 - Matão - SP - Brazil

Telephone 55.16.3382.8282

FAX: (Sales) 55.16.3382.1009 - (Parts) 55.16.3382.8297 - (Export) 55.16.3382.1003

e-mail: tatu@marchesan.com.br

www.marchesan.com.br

Notes
